

Part No. 212160-A
September 2001

4401 Great America Parkway
Santa Clara, CA 95054

Reference for the Business Policy Switch 2000 Command Line Interface Release 1.2

NORTEL
NETWORKS™

Copyright © 2001 Nortel Networks

All rights reserved. September 2001.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

Trademarks

Autotopology, BayStack, BaySecure, Business Policy Switch 2000, Nortel Networks, the Nortel Networks logo, Optivity, and Quick2Config are trademarks of Nortel Networks.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Java is a trademark of Sun Microsystems, Inc.

Acrobat and Adobe are trademarks of Adobe Systems, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks NA Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks NA Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Nortel Networks NA Inc. software license agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as "Software" in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH NORTEL NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License grant. Nortel Networks NA Inc. ("Nortel Networks") grants the end user of the Software ("Licensee") a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Nortel Networks Agent software or other Nortel Networks software products. Nortel Networks Agent software or other Nortel Networks software products are licensed for use under the terms of the applicable Nortel Networks NA Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Nortel Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Nortel Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Nortel Networks' and its licensors' confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Nortel Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee's facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Nortel Networks warrants each item of Software, as delivered by Nortel Networks and properly installed and operated on Nortel Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Nortel Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Nortel Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Nortel Networks will replace defective media at no charge if it is returned to Nortel Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Nortel Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Nortel Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Nortel Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL NORTEL NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF NORTEL NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO NORTEL NETWORKS FOR THE SOFTWARE LICENSE.

5. Government licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Nortel Networks of any such intended examination of the Software and may procure support and assistance from Nortel Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Nortel Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Nortel Networks copyright; those restrictions relating to use and disclosure of Nortel Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Nortel Networks the Software, user manuals, and all copies. Nortel Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Nortel Networks, 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN NORTEL NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST NORTEL NETWORKS UNLESS NORTEL NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Contents

Preface	19
About this guide	19
Before you begin	19
Text conventions	20
Related publications	21
How to get help	22
 Chapter 1	
CLI Basics	25
Stacking compatibility	26
Software version 1.2 compatibility with BayStack 450 switches	27
CLI command modes	28
Port numbering	32
Port lists	33
IP notation	33
Accessing the CLI	33
Setting the CLI password	36
cli password command	36
Getting help	37
Basic navigation	37
General navigation commands	38
Keystroke navigation	39
help command	40
no command	40
default command	41
logout command	41
enable command	41
configure command	42

interface command	42
disable command	43
end command	43
exit command	43
Managing basic system information	44
show sys-info command	44
show stack-info command	45
renumber unit command	46
Managing MAC address forwarding database table	46
show mac-address-table command	47
mac-address-table aging-time command	48
default mac-address-table aging-time command	49
Displaying and setting stack operational mode	49
show stack-oper-mode command	50
stack oper-mode command	50

Chapter 2

General CLI commands..... 53

Setting the terminal	54
show terminal command	54
default terminal command	54
terminal command	55
Pinging	56
ping command	56
Automatically loading configuration file	57
configure network command	57
show config-network command	59
Assigning and clearing IP addresses	59
ip address command	60
no ip address command	61
ip default-gateway command	61
no ip default-gateway command	62
show ip command	63
Setting Telnet access	64
show telnet-access command	65

telnet-access command	66
no telnet-access command	67
default telnet-access command	68
Setting server for Web-based management	68
web-server	69
no web-server	69
Setting boot parameters	69
boot command	70
ip bootp server command	70
no ip bootp server command	71
default ip bootp server command	71
Setting TFTP parameters	72
show tftp-server command	72
tftp-server command	73
no tftp-server command	73
copy config tftp command	73
copy tftp config command	74
Upgrading images	75
download command	75
Displaying interfaces	76
show interfaces command	76
Setting SNMP parameters	77
snmp-server command	78
no snmp-server command	79
snmp trap link-status command	80
no snmp trap link-status command	80
default snmp trap link-status command	81
Setting the system event log	82
show logging	82
set logging	83
no set logging	84
default set logging	84
clear logging command	84
Displaying port statistics	85
show port-statistics command	85

clear-stats command	87
Enabling or disabling a port	87
shutdown command	87
no shutdown command	88
Setting port speed	89
speed command	89
default speed command	90
duplex command	90
default duplex command	91
Enabling Autopology	92
autotopology command	92
no autotopology command	93
default autotopology command	93
Enabling flow control	93
flowcontrol command	94
no flowcontrol command	94
default flowcontrol command	95
Enabling rate-limiting	96
show rate-limit command	96
rate-limit command	97
no rate-limit command	98
default rate-limit command	99

Chapter 3

Security..... 101

Using the IP manager list	101
show ipmgr command	102
ipmgr command for management system	103
no ipmgr command for management system	104
ipmgr command for source IP address	105
no ipmgr command for source IP address	105
Using MAC address security	106
show mac-security command	106
mac-security command	107
mac-security mac-address-table address command	108

mac-security security-list command	109
no mac-security command	110
no mac-security mac-address-table command	110
no mac-security security-list command	111
mac-security command for a specific port	111
Using EAPOL-based security	112
show eapol command	112
eapol command	113
eapol command for modifying parameters	113
Using RADIUS authentication	115
show radius-server command	115
radius-server command	116
no radius-server command	117
 Chapter 4	
Spanning Tree, MLT, and Port-Mirroring	119
Using spanning tree	119
show spanning-tree command	120
spanning-tree stp create command by STG	123
spanning-tree stp delete command by STG	124
spanning-tree stp enable command by STG	124
spanning-tree stp disable command by STG	125
spanning-tree command by STG	126
default spanning-tree command by STG	127
spanning-tree add-vlan command	127
spanning-tree remove-vlan command	128
spanning-tree command by port	129
default spanning-tree command by port	130
no spanning-tree command by port	131
Using MLT	132
show mlt command	132
mlt command	133
no mlt command	134
Using port-mirroring	135
show port-mirroring command	135

port-mirroring command	135
no port-mirroring command	137

Chapter 5

VLANs and IGMP 139

Increased VLAN support	139
Configuring and displaying VLANs	140
show vlan interface info command	141
show vlan interface vids command	142
vlan create command	143
vlan delete command	146
no vlan command	146
vlan name command	147
auto-pvid command	147
no auto-pvid command	147
vlan ports command	148
vlan members command	149
show vlan mac-address command	150
vlan mac-address command	151
no vlan mac-address command	151
Displaying multicast membership	152
show vlan multicast membership command	152
Using IGMP snooping	153
show vlan igmp command	153
vlan igmp command	154
default vlan igmp command	155

Chapter 6

Policy-enabled networks and QoS 157

Displaying QoS parameters	158
show qos command	158
Resetting	168
qosagent reset-default command	168
Configuring COPS	168
qosagent server-control command	169

Configuring QoS interface groups	169
qos if-assign command	170
qos if-group command	170
qos if-assign-list command	171
Configuring DSCP and 802.1p and queue associations	172
qos egressmap command	172
qos ingressmap command	173
qos queue-set-assignment command	174
Configuring QoS filters and filter groups	174
qos ip-filter command	175
qos ip-filter-set command	176
qos l2-filter command	177
qos l2-filter-set command	179
Configuring QoS actions	180
qos action command	180
Configuring QoS meters	181
qos meter command	182
Gathering QoS statistics	183
qosagent police-statistics command	183
Configuring QoS policies	184
qos policy command	184
Reordering packets	186
qosagent packet-reordering command	186
 Appendix A	
Command List	187
 Index	195

Figures

Figure 1	CLI command mode hierarchy	30
Figure 2	BPS 2000 banner	34
Figure 3	Main Menu for BPS 2000 console interface	35
Figure 4	help command output in privExec mode	40
Figure 5	show sys-info command output	45
Figure 6	show stack-info command output	46
Figure 7	show mac-address-table command output	48
Figure 8	show stack-oper-mode command output	50
Figure 9	show terminal command output	54
Figure 10	ping command responses	57
Figure 11	show config-network command	59
Figure 12	show ip command output	64
Figure 13	Telnet icon on Device Manager toolbar	64
Figure 14	show telnet-access command output	66
Figure 15	show tftp-server command output	72
Figure 16	download message	76
Figure 17	show interfaces command output	77
Figure 18	show logging command output	83
Figure 19	show port-statistics command output	86
Figure 20	show rate-limit command output	97
Figure 21	show ipmgr command output	103
Figure 22	show mac-security command output	107
Figure 23	show radius-server command output	116
Figure 24	show spanning-tree command output by port	122
Figure 25	show spanning-tree command output for spanning tree group	123
Figure 26	show mlt command output	133
Figure 27	show port-mirroring command output	135
Figure 28	show vlan interface info output	142
Figure 29	show vlan interface vids output	143

Figure 30	show vlan mac-address command output	151
Figure 31	show vlan multicast membership command output	153
Figure 32	show vlan igmp command output	154
Figure 33	show qos interface-groups command output	159
Figure 34	show qos interface-assignments command output	160
Figure 35	show qos egressmap command output	161
Figure 36	show qos ingressmap command output	162
Figure 37	show qos ip-filters command output	162
Figure 38	show qos ip-filter-sets command output	163
Figure 39	show qos l2-filters command output	163
Figure 40	show qos l2-filter-sets command output	164
Figure 41	show qos actions command output	164
Figure 42	show qos meters command output	165
Figure 43	show qos policies command output	165
Figure 44	show qos queue-sets command output	166
Figure 45	show qos queue-set-assignments command output	167
Figure 46	show qos agent command output	167
Figure 47	show qos statistics command output	168

Tables

Table 1	Command mode prompts and entrance/exit commands	31
Table 2	cli password command parameters and variables	37
Table 3	Keystroke navigation	39
Table 4	configure command parameters and variables	42
Table 5	interface command parameters and variables	43
Table 6	show mac-address-table command parameters and variables	47
Table 7	mac-address-table aging-time command parameters and variables	49
Table 8	stack oper-mode command parameters and variables	51
Table 9	default terminal command parameters and variables	55
Table 10	terminal command parameters and variables	56
Table 11	ping command parameters and variables	57
Table 12	configure network command parameters and variables	58
Table 13	ip address command parameters and variables	60
Table 14	no ip address command parameters and variables	61
Table 15	ip default-gateway command parameters and variables	62
Table 16	show ip command parameters and variables	63
Table 17	telnet-access command parameters and variables	67
Table 18	no telnet-access command parameters and variables	68
Table 19	web-server command parameters and variables	69
Table 20	boot command parameters and variables	70
Table 21	ip boot server command parameters and variables	71
Table 22	tftp-server command parameters and variables	73
Table 23	copy config tftp command parameters and variables	74
Table 24	copy tftp config command parameters and variables	74
Table 25	download command parameters and variables	75
Table 26	snmp-server command parameters and variables	78
Table 27	no snmp-server command parameters and variables	79
Table 28	snmp trap link-status command parameters and variables	80
Table 29	no snmp trap link-status command parameters and variables	81

Table 30	default snmp trap link-status command parameters and variables	81
Table 31	show logging command parameters and variables	82
Table 32	set logging command parameters and values	83
Table 33	clear logging command parameters and values	85
Table 34	show port-statistics command parameters and variables	85
Table 35	clear-stats command parameters and variables	87
Table 36	shutdown command parameters and variables	88
Table 37	no shutdown command parameters and variables	88
Table 38	speed command parameters and variables	89
Table 39	default speed command parameters and variables	90
Table 40	duplex command parameters and variables	91
Table 41	default duplex command parameters and variables	92
Table 42	flowcontrol command parameters and variables	94
Table 43	no flowcontrol command parameters and variables	95
Table 44	default flowcontrol command parameters and variables	95
Table 45	rate-limit command parameters and variables	98
Table 46	no rate-limit command parameters and variables	98
Table 47	default rate-limit command parameters and variables	99
Table 48	ipmgr command for system management parameters and variables . . .	104
Table 49	no ipmgr command for management system parameters and variables	104
Table 50	ipmgr command for source IP addresses parameters and variables . . .	105
Table 51	no ipmgr command for source IP addresses parameters and variables	106
Table 52	show mac-security command parameters and variables	107
Table 53	mac-security command parameters and values	108
Table 54	mac-security mac-address-table address command parameters and values	109
Table 55	mac-security security-list command parameters and values	109
Table 56	no mac-security mac-address-table command parameters and values .	110
Table 57	no mac-security security-list command parameters and values	111
Table 58	mac-security command for a single port parameters and variables	112
Table 59	eapol command parameters and variables	113
Table 60	eapol command for modifying parameters and variables	114
Table 61	radius-server command parameters and variables	116
Table 62	show spanning-tree command parameters and variables	121
Table 63	spanning-tree stp create command parameters and variables	124

Table 64	spanning-tree stp delete command parameters and variables	124
Table 65	spanning-tree stp enable command parameters and variables	125
Table 66	spanning-tree stp disable command parameters and variables	125
Table 67	spanning-tree command by STG parameters and variables	126
Table 68	default spanning-tree command by STG parameters and variables . . .	127
Table 69	spanning-tree add-vlan command parameters and variables	128
Table 70	spanning-tree remove-vlan command parameters and variables	129
Table 71	spanning-tree command by port parameters and variables	130
Table 72	default spanning-tree command by port parameters and variables . . .	131
Table 73	no spanning-tree command by port parameters and variables	132
Table 74	show mlt command parameters and variables	133
Table 75	mlt command parameters and variables	134
Table 76	no mlt command parameters and variables	134
Table 77	port-mirroring command parameters and variables	136
Table 78	show vlan command interface info parameters and variables	141
Table 79	show vlan command interface vids parameters and variables	143
Table 80	vlan create command parameters and variables	144
Table 81	vlan delete command parameters and variables	146
Table 82	no vlan command parameters and variables	146
Table 83	vlan name command parameters and variables	147
Table 84	vlan ports command parameters and variables	148
Table 85	vlan members command parameters and variables	149
Table 86	show vlan mac-address command parameters and variables	150
Table 87	vlan mac-address command parameters and variables	151
Table 88	no vlan mac-address command parameters and variables	152
Table 89	show vlan multicast membership command parameters and variables .	152
Table 90	show igmp command parameters and variables	154
Table 91	vlan igmp command parameters and variables	155
Table 92	default vlan igmp command parameters and variables	155
Table 93	show qos command parameters and variables	158
Table 94	qosagent server-control command parameters and variables	169
Table 95	qos if-assign command parameters and variables	170
Table 96	qos if-group command parameters and variables	171
Table 97	qos if-assign-list command parameters and variables	171
Table 98	qos egressmap command parameters and variables	173

Table 99	qos ingressmap command parameters and variables	173
Table 100	qos queue-set-assignment command parameters and variables	174
Table 101	qos ip-filter command parameters and variables	175
Table 102	qos ip-filter-set command parameters and variables	176
Table 103	qos l2-filter command parameters and variables	177
Table 104	qos l2-filter-set command parameters and variables	179
Table 105	qos action command parameters and variables	180
Table 106	qos meter command parameters and variables	182
Table 107	qosagent police-statistics command parameters and variables	184
Table 108	qos policy command parameters and variables	185
Table 109	qosagent packet-reordering command parameters and variables	186
Table 110	CLI Command List	187

Preface

The Nortel Networks* Business Policy Switch 2000* command line interface (CLI) is one tool used to configure and manage a Business Policy Switch 2000. The CLI allows you to set up, configure, and manage your BPS 2000.

You can also use the Java* Device Manager graphical user interface (GUI), the Web-based management system GUI, and the console interface (CI) menus to configure and manage the switch. For more information on these management systems, refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2*, *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2*, and *Using the Business Policy Switch 2000 Software Version 1.2*.

For general information on using and configuring the BPS 2000, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

About this guide

This guide provides information about using the features and capabilities of the CLI to manage switching operations in the BPS 2000, as well as a complete list of CLI commands.

Before you begin

This guide is intended for network administrators with the following background:

- Basic knowledge of networks, bridging, and IP
- Familiarity with networking concepts and terminology
- Basic knowledge of network topologies

Before using this guide, you must complete the procedures discussed in the *Business Policy Switch 2000 Installation Instructions*.

Text conventions

angle brackets (< >)	<p>Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is <code>ip default-gateway <XXX.XXX.XXX.XXX></code>, you enter <code>ip default-gateway 192.32.10.12</code></p>
braces ({ })	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is: <code>http-server {enable disable}</code> the options for are <code>enable</code> or <code>disable</code>.</p>
brackets ([])	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is: <code>show ip [bootp]</code>, you can enter either: <code>show ip</code> or <code>show ip bootp</code>.</p>
plain Courier text	<p>Indicates command syntax and system output.</p> <p>Example: TFTP Server IP Address: 192.168.100.15</p>
vertical line	<p>Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command.</p> <p>Example: If the command syntax is: <code>cli password <serial telnet></code>, you must enter either <code>cli password serial</code> or <code>cli password telnet</code>, but not both.</p>
H.H.H.	<p>Enter a MAC address in this format (XXXX.XXXX.XXXX).</p>

Related publications

For more information about managing or using Business Policy Switch 2000, refer to the following publications:

- *Release Notes for the Business Policy Switch 2000 Software Version 1.2* (part number 210676-D)
- *Installing the Business Policy Switch 2000* (part number 209319-A)
- *Using the Business Policy Switch 2000 Software Version 1.2* (part number 208700-B)
- *Getting Started with the Business Policy Switch 2000 Management Software Operations* (part number 209321-A)
- *Reference for the Business Policy Switch 2000 Management Software Version 1.2* (part number 209322-B)
- *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* (part number 209570-B)

- *Installing and Administering Optivity Quick2Config 2.2* (part number 207809-B)
- *Using the Optivity Quick2Config 2.2 Client Software* (part number 207810-B)
- *Configuring Business Policy Switches with Optivity Quick2Config 2.2* (part number 311208-A Rev 00)
- *Release Notes for Optivity Quick2Config 2.2 for Business Policy Switch 2000 2.2.1* (part number 310621-A)
- *Installing Optivity Policy Services for Business Policy Switch* (part number 306972-C Rev 00)
- *Managing Policy Information in Optivity Policy Services for Business Policy Switch* (part number 306969-D Rev 00)
- *Release Notes for Optivity Policy Services for Business Policy Switch Version 1.0* (part number 306975-C Rev 00)
- *Task Map - Installing OPS for BPS Product Family* (part number 306976-C Rev 00)
- *Known Anomalies for Optivity Policy Services for Business Policy Switch Version 1.0* (part number 306974-C Rev 00)

You can print selected technical manuals and release notes free, directly from the Internet. Go to the www.nortelnetworks.com/documentation URL. (The product family for the BPS 2000 is Data and Internet.) Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe® Acrobat Reader® to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the www.adobe.com URL to download a free copy of the Adobe Acrobat Reader.

How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone
Europe, Middle East, and Africa	(33) (4) 92-966-968
North America	(800) 4NORTEL or (800) 466-7835
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the www12.nortelnetworks.com/ URL and click ERC at the bottom of the page.

Chapter 1

CLI Basics

You can manage the BPS 2000 with a number of tools. You can use either graphical user interface (GUI), the Java Device Manager (DM) or the Web-based management system. You can use the console interface (CI menus), or you can use the command line interface (CLI). (For more information on using the DM, refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2*. For more information on using the Web-based management system, refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2*. For more information on using the CI menus, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

The BPS 2000 command line interface (CLI) is a management tool that provides methods for configuring, managing, and monitoring the operational functions of the switch. You access the CLI through a direct connection to the switch console port, or remotely using Telnet. For a complete, alphabetical list of CLI commands, refer to Appendix A.

You can use the CLI interactively, or you can load and execute CLI “scripts.” CLI scripts are loaded in one of the following ways:

- By entering the `configure network` command.
- By manually loading the script in the console menu.
- By automatically loading the script at boot-up

This chapter discusses the following CLI topics:

- [“Stacking compatibility,”](#) next
- [“Software version 1.2 compatibility with BayStack 450 switches”](#) on page 27
- [“CLI command modes”](#) on page 28
- [“Port numbering”](#) on page 32
- [“IP notation”](#) on page 33

- [“Accessing the CLI” on page 33](#)
- [“Setting the CLI password” on page 36](#)
- [“Getting help” on page 37](#)
- [“Basic navigation” on page 37](#)
- [“Managing basic system information” on page 44](#)
- [“Managing MAC address forwarding database table” on page 46](#)
- [“Displaying and setting stack operational mode” on page 49](#)

Stacking compatibility

You can stack the BPS 2000 up to 8 units high. There are two types of stacks:

- Pure BPS 2000—This stack has *only* BPS 2000 switches. It is sometimes referred to as a pure stack. The stack operational mode for this type of stack is Pure BPS 2000 Mode.
- Hybrid—This stack has a combination of BPS 2000 switches *and* BayStack* 450 and/or BayStack 410 switches. It is sometimes referred to as a mixed stack. The stack operational mode for this type of stack is Hybrid Mode.

When you work with the BPS 2000 in standalone mode, you should ensure that the stack operational mode shows Pure BPS 2000 Mode, and does not show Hybrid Mode.

All BPS 2000 switches in the stack must be running the identical version of software, and all the BayStack switches must be running the identical version of software.

When you are working with a mixed stack, you *must* ensure that the Interoperability Software Version Numbers (ISVN) are identical. That is, the ISVN number for the BayStack 450 switch and BayStack 410 switch must have the same ISVN as the BPS 2000. If the ISVNs are not the same, the stack does not operate.

In sum, the stacking software compatibility requirements are as follows:

- Pure BPS 2000 stack—All units must be running the same software version.

- Pure BayStack 450 stack—All units must be running the same software version.
- Hybrid stack:
 - All BPS 2000 units must be running the same software version.
 - All BayStack 410 units must be running the same software version.
 - All BayStack 450 units must be running the same software version.
 - All software versions must have the identical ISVN.

Refer to Appendix B of *Using the Business Policy Switch 2000 Software Version 1.2* for complete information on interoperability and compatibility between the BPS 2000 and BayStack switches.

Software version 1.2 compatibility with BayStack 450 switches

The BPS 2000 software version 1.2 is compatible with BayStack 450 software version 4.1.

When you are using a local console to access the BPS 2000 software version 1.2 features with a Hybrid, or mixed, stack (BPS 2000 and BayStack 450 and 410 switches in the same stack), you must plug your local console into a BPS 2000 unit.

To find out which version of the BPS 2000 software is running, use the console interface (CI) menus or the Web-based management system:

- CI menus—From the main menu of the console, choose Systems Characteristics menu. The software currently running is displayed in sysDescr.
- Web-based management system—Open the System Information page, which is under Administration on the main menu. The software currently running is displayed in the sysDescription field.

You can use 256 port-, protocol-, and MAC SA-based VLANs for the stack with a Pure BPS 2000 stack running software version 1.2. (The maximum number of MAC SA-based VLANs available is 48). If you are working with a mixed, or hybrid, stack, you can use 64 VLANs for the entire stack. When you change from a Pure BPS 2000 Stack mode to a Hybrid Stack mode:

- If you have up to 64 VLANs on the Pure BPS 2000 Stack, they will be retained when you change to a Hybrid Stack.
- If you have more than 64 VLANs on the Pure BPS 2000 Stack, you will lose them all. The Hybrid Stack will return to the default VLAN configuration.

Also, a mixed, or hybrid, stack does not support multiple Spanning Tree Groups (STG). You have a single instance of STG when working with a mixed stack.

- If you have up to 64 VLANs on the Pure BPS 2000 Stack, they will be retained when you change to a Hybrid Stack.
- If you have more than 64 VLANs on the Pure BPS 2000 Stack, you will lose them all. The Hybrid Stack will return to the default VLAN configuration.

Also, a mixed, or hybrid, stack does not support multiple Spanning Tree Groups (STG). You have a single instance of STG when working with a mixed stack.

CLI command modes

Most CLI commands are available only under a certain command mode. The BPS 2000 has the following four command modes:

- User EXEC
- Privileged EXEC
- Global Configuration
- Interface Configuration

The User EXEC mode is the default mode; it is also referred to as exec. This command mode is the initial mode of access upon first powering-up the BPS 2000. In this command mode, the user can access only a subset of the total CLI commands; however, the commands in this mode are available while the user is in any of the other four modes. The commands in this mode are those you would generally need, such as ping and logout.


Commands in the Privileged EXEC mode are available to all other modes but the User EXEC mode. The commands in this mode allow you to perform basic switch-level management tasks, such as downloading the software image, setting passwords, and booting the BPS 2000. The Privileged EXEC mode is also referred to as `privExec` mode.

The last two command modes allow you to change the configuration of the BPS 2000. Changes made in these command modes are immediately applied to the switch configuration and saved to NVRAM.

The Global Configuration commands allow you to set and display general configurations for the switch, such as the IP address, SNMP parameters, the Telnet access, and VLANs. The Global Configuration mode is also referred to as `config` mode.

The Interface Configuration commands allow you to configure parameters for each port, such as speed, duplex mode, and rate-limiting. The Interface Configuration mode is also referred to as `config-if` mode.

Figure 1 provides an illustration of the hierarchy of BPS 2000 CLI command modes.

Figure 1 CLI command mode hierarchy

10194EA

You see a specific value for each command mode at the prompt line, and you use specific commands to enter or exit each command mode (Table 1). Additionally, you can only enter command modes from specific modes and only exit to specific command modes.

Table 1 Command mode prompts and entrance/exit commands

Command mode	Prompt	Enter/exit command
User EXEC (exec)	BPS2000>	<ul style="list-style-type: none"> • Default mode, automatically enter • <code>logout</code> or <code>exit</code> to quit CLI
Privileged EXEC (privExec)	BPS2000#	<ul style="list-style-type: none"> • <code>enable</code> to enter from User EXEC mode • <code>logout</code> or <code>exit</code> to quit CLI
Global Configuration (config)	BPS2000 (config) #	<ul style="list-style-type: none"> • <code>configure</code> to enter from Privileged EXEC mode • <code>logout</code> to quit CLI; <code>end</code> or <code>exit</code> to exit to Privileged EXEC mode
Interface Configuration (config-if)	BPS2000 (config-if) #	<ul style="list-style-type: none"> • <code>interface Fast Ethernet {<portnum> all}</code> to enter from Global Configuration mode • <code>logout</code> to quit CLI; <code>end</code> to exit to Privileged EXEC mode; <code>exit</code> to exit to Global Configuration mode

The prompt displays the switch name, BPS2000, and the current CLI command mode:

- User EXEC—BPS2000>
- Privileged EXEC—BPS2000#
- Global Configuration—BPS2000 (config) #
- Interface Configuration—BPS2000 (config-if) #

Refer to Appendix A, for a complete, alphabetical list of all CLI commands and where they are explained.

The initial command mode in CLI depends on your access level when you logged into the BPS 2000 CI menus:

- With no password protection, you enter the CLI in userExec mode, and use the `enable` command to move to the privExec command mode.
- If you logged into the CI menus with read-only access, you enter the CLI in userExec mode and cannot access any other CLI command modes.

- If you logged into the CLI menus with read-write access, you enter the CLI in `privExec` mode and use the commands to move to the other command modes.

Port numbering

The BPS 2000 operates either in standalone mode or in stack mode. The BPS 2000 has 24 10/100 Mb/s ports on the front, as well as an uplink slot that allows you to attach a media dependent adapter (MDA). The MDAs available for the BPS 2000 can have up to 4 ports. Thus, you have a maximum of 28 ports on one BPS 2000.

In stack mode, the BPS 2000 operates either in pure BPS 2000 stack mode or in hybrid stack mode. The hybrid stack mode is a combination of the BayStack 450 or 410 switches and BPS 2000 switches in one stack.

The port numbering scheme for the CLI is that if the BPS 2000 is in standalone mode, enter just the port number (possible range, depending on MDA, is 1 to 28).

The port numbering scheme when you are operating in either pure BPS 2000 stack mode or in the hybrid stack mode is to enter a number for the positions of the switch within the stack (possible range 1 to 8), a slash (/), and the number of the port on the BPS 2000 (possible range 1 to 28, depending on the MDA). For example, if you are configuring unit # 4 in the stack and the 16th port on that unit, enter 4/16. (Some commands allow you to enter `all`, which affects all ports in the system, or `none`, which affects none of the ports in the system.)

When you are operating in standalone mode, enter just the port number; do *not* enter an integer for unit or a slash.

The CLI uses the variable *portnum* (or port-num) in some commands; you should enter the port number according to the guidelines in the above paragraphs for the variable *portnum*.

To view the unit numbers in the stack, issue the `show stack-info` command (“[show stack-info command](#)” on page 45). You must be in the Privileged EXEC (`privExec`) mode to issue this command.

Refer to *Using the Business Policy Switch 2000 Software Version 1.2* guide, for more information on numbering units within the stack.

Port lists

You use port lists (the variable *portlist*) to specify a list of ports affected by a given command. Each element of the port list specifies either a single port or a range of ports, and each element is separated by a comma. For example, 2/3-7, 4/6, 5/1-3, 8/ALL indicates that all of the following ports will be affected by the command:

- Unit 2, ports 3 through 7
- Unit 4, port 6
- Unit 5, ports 1 through 3,
- Unit 8, all ports

IP notation

You enter IP addresses and subnet masks in one of the following two ways in the CLI. You can always enter an IP address in dotted decimal notation (XXX.XXX.XXX.XXX), specifying both the IP address and the subnet mask in dotted-decimal notation.

Or, when you are specifying both an IP address and a netmask, you may alternatively enter XXX.XXX.XXX.XXX/0-32, where XXX.XXX.XXX.XXX is the IP address in dotted-decimal notation and the value 0-32 specifies the number of bits starting from the left in the mask (for example, a value of 8 is 255.0.0.0).

Accessing the CLI

You access the CI menus using Telnet or a direct connection to the switch from a terminal or personal computer (PC). You can use any terminal or PC with a terminal emulator as the CLI command station. Be sure the terminal has the following features:

- 9600 bits per second (b/s), 8 data bits, 1 stop bit, no parity, no flow control

- Serial terminal-emulation program such as Terminal or Hyperterm for Windows NT* or Hyperterm for Windows* 95 or Windows 98
- Cable and connector to match the male DTE connector (DB-9) on the BPS 2000 console port, with the DCE/DTE switch on the switch management module set to DTE
- VT100 Arrows checked in the Terminal Preferences window under Terminal Options, and Block Cursor unchecked; VT-100/ANSI checked under Emulation

To access the CLI:


- 1 When you access the BPS 2000, the banner appears (Figure 2).

Figure 2 BPS 2000 banner

```
*****
* Nortel Networks
* Copyright (c) 1996,2000,2001
* All Rights Reserved
* Business Policy Switch 2000
* Ver: HW:AB3      FW:1.1.0.1    SW:v1.2.0.00    ISVN:2
*****

Enter Ctrl-Y to begin.
```

- 2 Press [Ctrl]+Y, and the Main Menu appears on the console screen (Figure 3) with the top line highlighted.

Figure 3 Main Menu for BPS 2000 console interface

- 3** Using the Down Arrow key, scroll down to Command Line Interface, and press [Enter]. The CLI cursor appears:

```
BPS2000>
```

The > sign at the end of the name of the switch indicates that the CLI opens in User EXEC mode. Refer to [“CLI command modes” on page 28](#), to select the command mode you want to use (and are authorized to use).

Setting the CLI password

You can set passwords using the `cli password` command for selected types of access using the CLI, Telnet, or RADIUS security.

For more information on Telnet access, refer to Chapter 3. For more information on using RADIUS security with the CLI, refer to Chapter 3.

cli password command

The `cli password` is in two forms and performs the following functions for either the switch or the entire stack:

- Changes the password for access through the serial console port and Telnet
- Specifies changing the password for serial console port or Telnet access and whether to authenticate password locally or with the RADIUS server

The syntax for the `cli password` commands are:

```
cli password {switch|stack} {ro|rw} <WORD> <WORD>
```

```
cli password {switch|stack} {serial|telnet}  
{none|local|radius}
```

The `cli password` command is in the config command mode.

[Table 2](#) describes the parameters and variables for the `cli password` command.

Table 2 cli password command parameters and variables

Parameters and variables	Description
switch stack	Specifies you are modifying the settings on the switch or on the stack. Note: If you omit this parameter, the system modifies the information for the current mode.
ro rw	Specifies you are modifying the read-only (ro) password or the read-write (rw) password.
<WORD> <WORD>	Enter your username for the first variable, and your password for the second variable.
serial telnet	Specifies you are modifying the password for serial console access or for Telnet access.
none local radius	Specifies the password you are modifying: <ul style="list-style-type: none">• none—disables the password• local—use the locally defined password for serial console or Telnet access• radius—use RADIUS authentication for serial console or Telnet access

Getting help

When you navigate through the CLI, online help is available at all levels. Entering a portion of the command, space, and a question mark (?) at the prompt results in a list of all options for that command.

Refer to [“help command” on page 40](#) for more information about the specific types of online help.

Basic navigation

This section discusses basic navigation around the CLI and between the command modes. As you see, the CLI incorporates various shortcut commands and keystrokes to simplify its use. The following topics are covered in this section:

- “General navigation commands,” next
- “Keystroke navigation” on page 39
- “help command” on page 40
- “no command” on page 40
- “default command” on page 41
- “logout command” on page 41
- “enable command” on page 41
- “configure command” on page 42
- “interface command” on page 42
- “disable command” on page 43
- “end command” on page 43
- “exit command” on page 43

General navigation commands

When you enter `?` at any point in the CLI session, the system retrieves help information for whatever portion of the command you entered thus far. Refer to “help command” on page 40 for more information.

The system records the last command in a CLI session. However, the last command is not saved across reboots.

Add the word `no` to the beginning of most CLI configuration commands to clear or remove the parameters of the actual command. For example, when you enter the command `ip stack address 192.32.154.126`, you set the IP stack address. However, when you enter `no ip stack address`, the system returns the IP address to zero. Refer to Appendix A for an alphabetical list of `no` commands.

Add the word `default` to the beginning of most CLI configuration commands returns the parameters of the actual command to the factory default values. Refer to Appendix A for an alphabetical list of `default` commands.

When you enter a portion of the command and the [Tab] key, the system finds the first unambiguous match of a command and displays that command. For example, if you enter `down`+ [Tab], the system displays `download`.

Keystroke navigation

You change the location of the cursor using the key combinations shown in Table 3.

Table 3 Keystroke navigation

Key combination	Function
[Ctrl]+A	Start of line
[Ctrl]+B	Back 1 character
[Ctrl]+C	Abort command
[Ctrl]+D	Delete the character indicated by the cursor
[Ctrl]+E	End of line
[Ctrl]+F	Forward 1 character
[Ctrl]+H	Delete character left of cursor (Backspace key)
[Ctrl]+I &	Command/parameter completion
[Ctrl]+K & [Ctrl]+R	Redisplay line
[Ctrl]+N or [Down arrow]	Next history command
[Ctrl]+P or [Up arrow]	Previous history command
[Ctrl]+T	Transpose characters
[Ctrl]+U	Delete entire line
[Ctrl]+W	Delete word left of cursor
[Ctrl]+X	Delete all characters to left of cursor
[Ctrl]+z	Exit Global Configuration mode (to Privileged EXEC mode)
?	Context-sensitive help
[Esc]+c & [Esc]+u	Capitalize character at cursor
[Esc]+l	Change character at cursor to lowercase
[Esc]+b	Move back 1 word
[Esc]+d	Delete 1 word to the right
[Esc]+f	Move 1 word forward

help command

The `help` command is in all command modes and displays a brief message about using the CLI help system. The syntax for the `help` command is:

```
help
```

The `help` command has no parameters or variables.

[Figure 4](#) shows the output from the `help` command.

Figure 4 `help` command output in `privExec` mode

```
BPS2000#help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a command argument
(e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you
want to know what arguments match the input (e.g. 'show pr?'.)
```

no command

The `no` command is always used as a prefix to a configuration command, and it negates the action performed by that command. The effect of the `no` command is to remove or to clear the configuration controlled by the specified command. Various `no` commands are in the `config` and `config-if` command modes.

Refer to Appendix A for an alphabetical listing of all `no` commands.



Note: Not all configuration commands support the `no` prefix command.

default command

The `default` command is always used as a prefix to a configuration command, and it restores the configuration parameters to default values. The default values are specified by each command.

Refer to Appendix A for an alphabetical listing of all `default` commands.



Note: Not all commands support the `default` prefix command.

logout command

The `logout` command logs you out of the CLI session and returns you to the Main Menu of the console interface (CI) menus (Figure 3). The syntax for the `logout` command is:

```
logout
```

The `logout` command is in all command modes.

The `logout` command has no parameters or variables.

enable command

The `enable` command changes the command mode from User EXEC to `privExec` mode. The syntax for the `enable` command is:

```
enable
```

The `enable` command is in the `exec` command mode.

The `enable` command has no parameters or variables.



Note: You must have read-write access to the BPS 2000 switch to be able to use the `enable` command.

configure command

The `configure` command moves you to the Global Configuration (`config`) command mode and identifies the source for the configuration commands. The syntax for the `configure` command is:

```
configure {terminal|network|memory}
```

The `configure` command is in the `privExec` command mode.

[Table 4](#) describes the parameters and variables for the `configure` command.

Table 4 `configure` command parameters and variables

Parameters and variables	Description
terminal network memory	Specifies the source for the configuration commands for the BPS 2000: <ul style="list-style-type: none">• <code>terminal</code>—allows you to enter config mode to enter configuration commands• <code>network</code>—allows you to set up parameters for auto-loading a script at boot-up or for loading and executing a script immediately• <code>memory</code>—not supported on BPS 2000

interface command

The `interface` command moves you to the Interface Configuration (`config-if`) command mode. The syntax for the `interface` command is:

```
interface FastEthernet {<port-num>|all}
```

The `interface` command is in the `config` command mode.

Table 5 describes the parameters and variables for the `interface` command.

Table 5 interface command parameters and variables

Parameters and variables	Description
<port-num> all	Specifies the port to configure: <ul style="list-style-type: none">• port-num—enter the port number or port list you want to be affected by all the commands issued in the config-if command mode• all—enter all to configure all interfaces on the system by all the commands issued in the config-if command mode

disable command

The `disable` command returns you to the User EXEC (`exec`) command mode. The syntax for the `disable` command is:

```
disable
```

The `disable` command is in the `privExec` command mode.

The `disable` command has no parameters or variables.

end command

The `end` command moves you to the `priv Exec` mode from either the Global Configuration (`config`) mode or the Interface Configuration (`config-if`) mode.

The syntax for the `end` command is:

```
end
```

The `end` command has no parameters or variables.

exit command

The `exit` command moves you around the command modes:

- In User EXEC (exec) and Privileged EXEC (privExec) command modes, `exit` allows you to quit the CLI session.
- In Global Configuration (config) mode, `exit` moves you back to the privExec command mode.
- In Interface Configuration (config-if) command mode, `exit` moves you back to the config mode.

The syntax for the `exit` command is:

```
exit
```

The `exit` command has no parameters or variables.

Managing basic system information

This section shows you how to view basic system information, such as the current software version and the stack mode; you can renumber the units within a stack. The following topics are covered:

- [“show sys-info command,” next](#)
- [“show stack-info command” on page 45](#)
- [“renumber unit command” on page 46](#)

Refer to *Using the Business Policy Switch 2000 Software Version 1.2*, for more information on the operation of the stack mode, including unit numbering.

show sys-info command

The `show sys-info` command displays the current system characteristics. The syntax for the `show sys-info` command is:

```
show sys-info
```

The `show sys-info` command is in the privExec command mode.

The `show sys-info` command has no parameters or variables.

Figure 5 displays sample output from the `show sys-info` command.

Figure 5 `show sys-info` command output

```
BPS2000#show sys-info
Operation Mode:    Switch
MAC Address:      01-6C-0F-8C-01-2E
Reset Count:      16
Last Reset Type:   Power Cycle
Power Status:      Primary Power
Local MDA Type:    None
sysDescr:          Business Policy Switch 2000
                   HW:AB3      FW:1.1.0.1   SW:v1.2.0.01  ISVN:2
sysObjectID:       1.3.6.1.4.1.45.3.40.1
sysUpTime:         6 days, 11:14:22
sysServices:       3
sysContact:        Jane Doe
sysName:           Engineering
sysLocation:       sylvan6-2
```

To change the system contact, name, or location, refer to the `snmp-server` command in Chapter 2.

show stack-info command

The `show stack-info` command displays the current stack information, which includes unit numbers, MDA and cascade attachments, and software version for all units. The syntax for the `show stack-info` command is:

```
show stack-info
```

The `show stack-info` command is in the `privExec` command mode.

The `show stack-info` command has no parameters or variables.

Figure 6 displays sample output from the `show stack-info` command.

Figure 6 show stack-info command output

```
BPS2000#show stack-info
Unit #  Switch Model      MDA Model Cascade MDA  SW Version
-----
1       BPS 2000             None      None      v1.2.0.01
```

renumber unit command

The `renumber unit` command changes the unit number of each switch in the stack. The syntax for the `renumber unit` command is:

```
renumber unit
```

The `renumber unit` command is in the config command mode.

The `renumber unit` command has no parameters or variables.



Note: This command does not take effect until you reset the stack.

Managing MAC address forwarding database table

This section shows you how to view the contents of the MAC address forwarding database table, as well as setting the age-out time for the addresses. The following topics are covered:

- [“show mac-address-table command,”](#) next
- [“mac-address-table aging-time command”](#) on page 48
- [“default mac-address-table aging-time command”](#) on page 49

show mac-address-table command

The `show mac-address-table` command displays the current contents of the MAC address forwarding database table. The syntax for the `show mac-address-table` command is:

```
show mac-address-table [vid <1-4094>] [aging-time] [address  
<H.H.H>]
```

The `show mac-address-table` command is in the `privExec` command mode.

[Table 6](#) describes the parameters and variables for the `show mac-address-table` command.

Table 6 show mac-address-table command parameters and variables

Parameters and variables	Description
vid <1-4094>	Enter the number of the VLAN you want to display the forwarding database of. Default is to display the management VLAN's database.
aging-time	Displays the time in seconds after which an unused entry is removed from the forwarding database.
address <H.H.H>	Displays a specific MAC address if it exists in the database. Enter the MAC address you want displayed.

[Figure 7](#) displays sample output from the `show mac-address-table` command.

Figure 7 show mac-address-table command output

```

BPS2000#show mac-address-table
      MAC Address      Port      MAC Address      Port
-----
00-60-fd-f8-68-48    2/2      00-80-2d-8c-2e-3f
00-80-2d-8f-66-de    2/2      00-80-2d-ca-93-57    2/2
00-90-27-3a-b4-be    2/2
00-90-27-9c-6e-78    2/2      00-a0-c9-04-ed-52    2/2
00-a0-cc-39-bf-39    2/2
00-a0-cc-5a-eb-17    2/2      00-a0-cc-5b-b2-9c    2/2
00-a0-cc-65-57-a8    2/2      00-a0-cc-d0-bd-f0    2/2
00-a0-cc-d1-4c-f8    2/2      00-a0-cc-d1-75-48    2/2
00-a0-cc-d1-7a-24    2/2
00-b0-d0-3d-ea-7a    2/2      00-b0-d0-b7-8e-f9    2/2
00-c0-4f-0e-d4-21    2/2      00-c0-4f-0e-d8-ce    2/2
00-c0-4f-40-5a-4d    2/2      00-c0-4f-6a-b8-8f    2/2
00-c0-4f-6a-b8-a1    2/2      00-c0-4f-8e-1f-18    2/2
00-c0-4f-8e-20-45    2/2      00-d0-09-4f-bf-18    2/2
00-d0-09-5b-06-81    2/2      00-e0-7b-10-1c-0a    2/2
00-e0-7b-10-1c-0b    2/2
BPS2000#

```

mac-address-table aging-time command

The `mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses. The syntax for the `mac-address-table aging-time` command is:

```
mac-address-table aging-time <time>
```

The `mac-address-table aging-time` command is in the config command mode.

[Table 7](#) describes the parameters and variables for the `mac-address-table aging-time` command.

Table 7 mac-address-table aging-time command parameters and variables

Parameters and variables	Description
time	Enter the aging time in seconds that you want for MAC addresses before they are flushed.

default mac-address-table aging-time command

The default `mac-address-table aging-time` command sets the time that the switch retains unseen MAC addresses to 300 seconds. The syntax for the `default mac-address-table aging-time` command is:

```
default mac-address aging-time
```

The `default mac-address-table aging-time` command is in the `config` command mode.

The `default mac-address-table aging-time` command has no parameters or variables.

Displaying and setting stack operational mode

This section shows you how to view and set the stack operational mode. The following topics are covered:

- [“show stack-oper-mode command,”](#) next
- [“stack oper-mode command”](#) on page 50

Refer to *Using the Business Policy Switch 2000 Software Version 1.2* for more information on the stack operation, including features requiring specific operational modes and adding switches to the stack.

show stack-oper-mode command

The `show stack-oper-mode` command displays the current operational mode of the stack and the mode set for the next switch reboot. The display shows either:

- Pure BPS 2000 Stack

or

- Hybrid Stack

The syntax for the `show stack-oper-mode` command is:


```
show stack-oper-mode
```

The `show stack-oper-mode` command is in the `privExec` command mode.

The `show stack-oper-mode` command has no parameters or variables.

[Figure 8](#) displays sample output from the `show stack-oper-mode` command.

Figure 8 show stack-oper-mode command output

A rounded rectangular box containing the sample output of the `show stack-oper-mode` command. The output consists of three lines: the command prompt, the current operational mode, and the next boot operational mode.

```
BPS2000#show stack-oper-mode
Current Operational Mode:  Pure BPS 2000 Stack
Next Boot Operational Mode:  Pure BPS 2000 Stack
```

stack oper-mode command

The `stack oper-mode` command allows you to set the stack operational mode, which becomes active at the next reboot of the switch or stack. The syntax for the `stack oper-mode` command is:

```
stack oper-mode {bps2000|hybrid}
```

The `stack oper-mode` command is in the `config` command mode.

[Table 8](#) describes the parameters and variables for the `stack oper-mode` command.

Table 8 stack oper-mode command parameters and variables

Parameters and variables	Description
bps2000 hybrid	Sets the stack operational mode for the next boot: <ul style="list-style-type: none">• bps2000—Pure BPS 2000 Stack mode. This means <i>only</i> BPS 2000 switches either standalone or in a stack.• hybrid—Hybrid Stack mode. This means a mixture of BPS 2000 and BayStack 450 or 410 switches in a stack.



Note: You must reboot the system for the stack operation mode you entered in the CLI to take effect.

Chapter 2

General CLI commands

In the BPS 2000, the Command Line Interface (CLI) commands allows you to display and modify the switch configuration while the switch is operating.

This chapter includes information about general switch maintenance, such as setting up access parameters, upgrading the software, and setting the speed. This chapter covers the following topics:

- [“Setting the terminal,” next](#)
- [“Pinging” on page 56](#)
- [“Assigning and clearing IP addresses” on page 59](#)
- [“Setting Telnet access” on page 64](#)
- [“Setting server for Web-based management” on page 68](#)
- [“Setting boot parameters” on page 69](#)
- [“Setting TFTP parameters” on page 72](#)
- [“Upgrading images” on page 75](#)
- [“Displaying interfaces” on page 76](#)
- [“Setting SNMP parameters” on page 77](#)
- [“Setting the system event log” on page 82](#)
- [“Displaying port statistics” on page 85](#)
- [“Enabling or disabling a port” on page 87](#)
- [“Setting port speed” on page 89](#)
- [“Enabling Autopology” on page 92](#)
- [“Enabling flow control” on page 93](#)
- [“Enabling rate-limiting” on page 96](#)

Setting the terminal

You can view the terminal settings, set them to default settings, or customize the terminal settings. This section covers:

- [“show terminal command,”](#) next
- [“default terminal command”](#) on page 54
- [“terminal command”](#) on page 55

show terminal command

The `show terminal` command displays the current serial port information, which includes connection speed, as well as the terminal width and length in number of characters. The syntax for the `show terminal` command is:


```
show terminal
```

The `show terminal` command is in the exec command mode.

The `show terminal` command has no parameters or variables.

[Figure 9](#) displays the output from the `show terminal` command.

Figure 9 show terminal command output



```
BPS2000#show terminal
Terminal speed: 9600
Terminal width: 79
Terminal length: 23
BPS2000#
```

default terminal command

The `default terminal` command configures default settings for the terminal. These settings are transmit and receive speeds, terminal length, and terminal width. The syntax for the `default terminal` command is:

```
default terminal {speed|width|length}
```

The `default terminal` command is in the exec mode.

[Table 9](#) describes the parameters and variables for the `default terminal` command.

Table 9 default terminal command parameters and variables

Parameters and variables	Description
speed width length	Sets the defaults <ul style="list-style-type: none">• speed—transmit and receive baud rates for the terminal; default is 9600 baud• width—width of the terminal display; default is 79 characters• length—Length of the terminal display; default is 24 characters

terminal command

The `terminal` command configures the settings for the terminal. These settings are transmit and receive speeds, terminal length, and terminal width. The syntax of the `terminal` command is:

```
terminal speed {2400|4800|9600|19200|38400}|length  
<1-132>|width <1-132>
```

The `terminal` command is in the exec mode.

[Table 10](#) describes the parameters and variables for the `terminal` command.

Table 10 terminal command parameters and variables

Parameters and variables	Description
speed {2400 4800 9600 19200 38400}	Sets the transmit and receive baud rates for the terminal. You can set the speed at one of the five options shown; default is 9600.
length	Sets the length of the terminal display in characters; default is 24.
width	Sets the width of the terminal displaying characters; default 79.

Pinging

To ensure that the BPS 2000 has connectivity to the network, ping a device you know is connected to this network.

ping command

The `ping` command tests the network connection to another network device. The command sends an Internet Control Message Protocol (ICMP) packet from the switch to the target device. The local IP address must be set before issuing the `ping` command.



Note: Refer to [“Assigning and clearing IP addresses” on page 59](#) for information on setting IP addresses.

The syntax for the `ping` command is:

```
ping <XXX.XXX.XXX.XXX>
```

The `ping` command is in the `exec` command mode.

[Table 11](#) describes the parameters and variables for the `ping` command.

Table 11 ping command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Specify the IP address of the target device in dotted-decimal notation.

If the device receives the packet, it sends a ping reply. When the switch receives the reply, it displays a message indicating that the specified IP address is alive. If no reply is received, a message indicates that the address is not responding.

[Figure 10](#) displays sample ping responses.

Figure 10 ping command responses

```
BPS2000#ping 10.10.40.29
Host is reachable
BPS2000#ping 10.10.41.29
Host is not reachable
```

Automatically loading configuration file

This section discusses how to download a configuration file when the system boots. You use standard CLI commands to modify the configuration file you want to download. This section covers these commands:

- [“configure network command,”](#) next
- [“show config-network command”](#) on page 59

configure network command

The `configure network` command allows you to load and execute a script immediately and to configure parameters to automatically download a configuration file when you reboot the switch or stack. The syntax for the `configure network` command is:

```
configure network [load-on-boot  
{disable|use-bootp|use-config}] [filename <WORD>] [address  
<XXX.XXX.XXX.XXX>]
```

The `configure network` command is in the exec mode.



Note: When you enter `configure network` with no parameters, the system prompts you for the script file name and TFTP server address and then downloads the script.

[Table 12](#) describes the parameters and variables for the `configure network` command.

Table 12 configure network command parameters and variables

Parameters and variables	Description
load-on-boot {disable use-bootp use-config}	<p>Specifies the settings for automatically loading a configuration file when the system boots:</p> <ul style="list-style-type: none">• <code>disable</code>—disables the automatic loading of config file• <code>use-boot</code>—specifies using the BootP file as the automatically loaded config file• <code>use-config</code>—specifies using the ASCII configuration file as the automatically loaded config file <p>Note: If you omit this parameter, the system immediately downloads and runs the ASCII config file.</p>
filename <WORD>	<p>Specifies the file name.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured file name.</p>
address <XXX.XXX.XXX.XXX>	<p>Specifies the TFTP server from which to load the file. Enter the IP address in dotted-decimal notation.</p> <p>Note: If you omit this parameter and do not specify BootP, the system uses the configured address.</p>



Note: When you specify the file name or address, these parameters will be changed at the next reboot, even if you do not specify load-on-boot.

show config-network command

The `show config-network` command displays information regarding the automatic loading of the configuration file, including the current status of this feature, the file name, the TFTP server address, and the status of the previous automatic configuration command. The syntax for the `show config-network` command is:

```
show config-network
```

The `show config-network` command is in the `privExec` mode.

The `show config-network` command has no parameters or values.

The output for the `show config-network` command is shown in [Figure 11](#),

Figure 11 `show config-network` command

```
BPS2000(config)#show config-network
Auto-Load Configuration On Boot:  Disabled
Configuration Filename:
TFTP Server IP Address:  192.168.100.15
Last Auto Configuration Status:  Passed
```

Assigning and clearing IP addresses

Using the CLI, you can assign IP addresses and gateway addresses, clear these addresses, and view configured IP addresses. This sections covers these topics:

- “[ip address command](#),” next
- “[no ip address command](#)” on page 61
- “[ip default-gateway command](#)” on page 61

- [“no ip default-gateway command” on page 62](#)
- [“show ip command” on page 63](#)

ip address command

The `ip address` command sets the IP address and subnet mask for the switch or a stack. The syntax for the `ip address` command is:

```
ip address [stack|switch] <XXX.XXX.XXX.XXX> [netmask  
<XXX.XXX.XXX.XXX>]
```

The `ip address` command is in the config command mode.

If you do not enter either the stack or switch parameter, the system automatically modifies the stack IP address when in stack mode and modifies the switch IP address when in standalone mode.

[Table 13](#) describes the parameters and variables for the `ip address` command.

Table 13 ip address command parameters and variables

Parameters and variables	Description
stack switch	Sets the stack the IP address and netmask or the switch IP address and netmask.
XXX.XXX.XXX.XXX	Enter IP address in dotted decimal notation; netmask is optional.
netmask	Set the IP subnet mask for the stack or switch.



Note: When you change the IP address or subnet mask, you may lose connection to Telnet and the Web.

no ip address command

The `no ip address` command clears the IP address and subnet mask. This command sets the IP address and subnet mask for a switch or a stack to all zeros (0). The syntax for the `no ip address` command is:

```
no ip address {stack|switch}
```

The `no ip address` command is in the config command mode.

[Table 14](#) describes the parameters and variables for the `no ip address` command.

Table 14 no ip address command parameters and variables

Parameters and variables	Description
stack switch	Zeroes out the stack IP address and subnet mask or the switch IP address and subnet mask.



Note: When you change the IP address or subnet mask, you may lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial console port to configure a new IP address.

ip default-gateway command

The `ip default-gateway` command sets the IP default gateway address for a switch or a stack to use. The syntax for the `ip default-gateway` command is:

```
ip default-gateway <XXX.XXX.XXX.XXX>
```

The `ip default-gateway` command is in the config command mode.

[Table 15](#) describes the parameters and variables for the `ip default-gateway` command.

Table 15 `ip default-gateway` command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Enter the dotted-decimal IP address of the default IP gateway.



Note: When you change the IP gateway, you may lose connection to Telnet and the Web.

no ip default-gateway command

The `no ip default-gateway` command sets the IP default gateway address to zeros (0). The syntax for the `no ip default-gateway` command is:

```
no ip default-gateway
```

The `no ip default-gateway` command is in the config command mode.

The `no ip default-gateway` command has no parameters or variables.



Note: When you change the IP gateway address, you may lose connection to Telnet and the Web. You also may disable any new Telnet connection be required to connect to the serial console port to configure a new IP gateway address.

show ip command

The `show ip` command displays the IP configurations, specifically BootP mode, stack address, switch address, subnet mask, and gateway address. This command displays these parameters for what is configured, what is in use, and the last BootP. The syntax for the `show ip` command is:

```
show ip [bootp] [default-gateway] [address [stack|switch]]
```

The `show ip` command is in the exec command mode. If you do not enter any parameters, this command displays all the IP-related configuration information.

[Table 16](#) describes the parameters and variables for the `show ip` command.

Table 16 show ip command parameters and variables

Parameters and variables	Description
bootp	Displays BootP-related IP information.
default-gateway	Displays the IP address of the default gateway.
address	Displays the current IP address.
stack switch	Specifies current IP address of the stack or the switch.

[Figure 12](#) displays a sample output of the `show ip` command.

Figure 12 show ip command output

```

BPS2000>show ip
BootP Mode: BootP Disabled

           Configured           In Use           Last BootP
-----
Stack IP Address: 10.10.40.29      10.10.40.29      0.0.0.0
Switch IP Address: 0.0.0.0          0.0.0.0          0.0.0.0
Subnet Mask:      255.255.255.0    255.255.255.0    0.0.0.0
Default Gateway:  10.10.40.1       10.10.40.1       0.0.0.0
BPS2000>

```

Setting Telnet access

You can also access the CLI through a Telnet session. To access the CLI remotely, the management port must have an assigned IP address and remote access must be enabled. You can log on to the switch using Telnet from a terminal that has access to the BPS 2000.

To open a Telnet session from Device Manager, click on the Telnet icon on the toolbar ([Figure 13](#)) or click Action > Telnet on the Device Manager toolbar.

Figure 13 Telnet icon on Device Manager toolbar

Note: Multiple users can access the CLI system simultaneously, through the serial port, Telnet, and modems. The maximum number of simultaneous users is four plus one each at the serial port for a total of 12 users on the stack. All users can configure simultaneously.

You can view the Telnet allowed IP addresses and settings, change the settings, or disable the Telnet connection. This section covers the following topics:

- [“show telnet-access command,” next](#)
- [“telnet-access command” on page 66](#)
- [“no telnet-access command” on page 67](#)
- [“default telnet-access command” on page 68](#)

show telnet-access command

The `show telnet-access` command displays the current settings for Telnet access. The syntax for the `show telnet-access` command is:

```
show telnet-access
```

The `show telnet-access` command is in the `privExec` command mode.

The `show telnet-access` command has no parameters or variables.

[Figure 14](#) displays sample output from the `show telnet-access` command.

Figure 14 show telnet-access command output

```

BPS2000#show telnet-access
TELNET Access:      Enabled
Login Timeout:      1 minute(s)
Login Retries:      3
Inactivity Timeout: 15 minute(s)
Event Logging:      All
Allowed Source IP Address  Allowed Source Mask
-----
0.0.0.0              0.0.0.0
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
255.255.255.255      255.255.255.255
BPS2000#

```

telnet-access command

The `telnet-access` command allows you to configure the Telnet connection used to manage the switch. The syntax for the `telnet-access` command is:

```

telnet-access [enable|disable] [login-timeout <1-10>] [retry
<1-100>] [inactive-timeout <0-60>] [logging
{none|access|failures|all}] [source-ip <1-10>
<XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]

```

The `telnet-access` command is in the config command mode.

[Table 17](#) describes the parameters and variables for the `telnet-access` command.

Table 17 telnet-access command parameters and variables

Parameters and variables	Description
<code>enable disable</code>	Enables or disables Telnet connections.
<code>login-timeout <1-10></code>	Specifies the time in minutes you want to wait between initial Telnet connection and accepted password before closing the Telnet connection; enter an integer between 1 and 10.
<code>retry <1-100></code>	Specifies the number of times the user can enter an incorrect password before closing the connection; enter an integer between 1 and 100.
<code>inactive timeout <0-60></code>	Specifies in minutes how long to wait before closing an inactive session; enter an integer between 0 and 60.
<code>logging {none access failures all}</code>	Specifies what types of events you want to save in the event log: <ul style="list-style-type: none"> • none—do not save access events in the log • access—save access events in the log • failure—save failed access events in the log • all—save all access events in the log
<code>[source-ip <1-10> <XXX.XXX.XXX.XXX>[mask <XXX.XXX.XXX.XXX>]</code>	Specifies the source IP address from which connections are allowed. Enter the IP address either as an integer or in dotted-decimal notation. Specifies the subnet mask from which connections are allowed; enter IP mask in dotted-decimal notation. Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.

no telnet-access command

The `no telnet-access` command allows you to disable the Telnet connection. The syntax for the `no telnet-access` command is:

```
no telnet-access [source-ip [<1-10>]]
```

The `no telnet-access` command is in the config mode.

[Table 18](#) describes the parameters and variables for the `no telnet-access` command.

Table 18 no telnet-access command parameters and variables

Parameters and variables	Description
source-ip [<1-10>]	<p>Disables the Telnet access.</p> <p>When you do <i>not</i> use the optional parameter, the source-ip list is cleared, meaning the 1st index is set to 0.0.0.0./0.0.0.0. and the 2nd to 10th indexes are set to 255.255.255.255/255.255.255.255. When you <i>do</i> specify a source-ip value, the specified pair is set to 255.255.255.255/255.255.255.255.</p> <p>Note: These are the same source IP addresses as in the IP Manager list. For more information on the IP Manager list, refer to Chapter 3.</p>

default telnet-access command

The `default telnet-access` command sets the Telnet settings to the default values. The syntax for the `default telnet-access` command is:

```
default telnet-access
```

The `default telnet-access` command is in the config command mode.

The `default telnet-access` command has no parameters or values.

Setting server for Web-based management

You can enable or disable the Web server to use for the Web-based management system. Refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* for information on the Web-based management system. This section discusses the following commands:

- “web-server,” next
- “no web-server” on page 69

web-server

The `web-server` command enables or disables the Web server that you use for Web-based management. The syntax for the `web-server` command is:

```
web-server {enable|disable}
```

The `web-server` command is in the config mode

[Table 19](#) describes the parameters and variables for the `web-server` command.

Table 19 web-server command parameters and variables

Parameters and variables	Description
enable disable	Enables or disables the Web server.

no web-server

The `no web-server` command disables the Web server that you use for Web-based management. The syntax for the `no web-server` command is:

```
no web-server
```

The `no web-server` command is in the config mode.

The `no web-server` command has no parameters or values.

Setting boot parameters

You can reboot the switch or stack and configure BootP. The topics covered in this section are:

- [“boot command,”](#) next
- [“ip bootp server command”](#) on page 70

- [“no ip bootp server command” on page 71](#)
- [“default ip bootp server command” on page 71](#)

boot command

The `boot` command performs a soft-boot of the switch or stack. The syntax for the `boot` command is:

```
boot [default] [unit <unitno>]
```

The `boot` command is in the `privExec` command mode.

[Table 20](#) describes the parameters and variables for the `boot` command.

Table 20 boot command parameters and variables

Parameters and variables	Description
default	Restores switch or stack to factory-default settings after rebooting.
unit <unitno>	Specifies which unit of the stack will be rebooted. This command is available only in stack mode. Enter the unit number of the switch you want to reboot.



Note: When you reset to factory defaults, the switch or stack retains the stack operational mode, last reset count, and reason for last reset; these three parameters are not defaulted to factory defaults.

ip bootp server command

The `ip bootp server` command configures BootP on the current instance of the switch or server. The syntax for the `ip bootp server` command is:

```
ip bootp server {last|needed|disable|always}
```

The `ip bootp server` command is in the config command mode.

Table 21 describes the parameters and variables for the `ip boot server` command.

Table 21 ip boot server command parameters and variables

Parameters and variables	Description
last needed disable always	Specifies when to use BootP: <ul style="list-style-type: none">• last—use BootP or the last known address• needed—use BootP only when needed• disable—never use BootP• always—Always use BootP

no ip bootp server command

The `no ip bootp server` command disables the BootP server. The syntax for the `no ip bootp server` command is:

```
no ip bootp server
```

The `no ip bootp server` command is in the config command mode.

The `no ip bootp server` command has no parameters or values.

default ip bootp server command

The `default ip bootp server` command disables the BootP server. The syntax for the `default ip bootp server` command is:

```
default ip bootp server
```

The `default ip bootp server` command is in the config command mode.

The `default ip bootp server` command has no parameters or values.

Setting TFTP parameters

You can display the IP address of the TFTP server, assign an IP address you want to use for a TFTP server, copy a configuration file to the TFTP server, or copy a configuration file from the TFTP server to the switch to use to configure the switch. This section covers:

- [“show tftp-server command,”](#) next
- [“tftp-server command”](#) on page 73
- [“no tftp-server command”](#) on page 73
- [“copy config tftp command”](#) on page 73
- [“copy tftp config command”](#) on page 74

show tftp-server command

The `show tftp-server` command displays the IP address of the server used for all TFTP-related transfers. The syntax for the `show tftp-server` command is:


```
show tftp-server
```

The `show tftp-server` command is in the `privExec` command mode.

The `show tftp-server` command has no parameters or variables.

[Figure 15](#) displays a sample output of the `show tftp-server` command.

Figure 15 show tftp-server command output



```
BPS2000#show tftp-server
TFTP Server IP address : 192.168.100.15
BPS2000#
```


tftp-server command

The `tftp-server` command assigns the address for the stack or switch to use for TFTP services. The syntax of the `tftp-server` command is:

```
tftp-server <XXX.XXX.XXX.XXX>
```

The `tftp-server` command is in the config command mode.

[Table 22](#) describes the parameters and variables for the `tftp-server` command.

Table 22 tftp-server command parameters and variables

Parameters and variables	Description
XXX.XXX.XXX.XXX	Enter the dotted-decimal IP address of the server you want to use for TFTP services.

no tftp-server command

The `no tftp-server` command clears the TFTP server IP address to 0.0.0.0. The syntax of the `no tftp-server` command is:

```
no tftp-server
```

The `no tftp-server` command is in the config command mode.

The `no tftp-server` command has no parameters or values.

copy config tftp command

The `copy config tftp` command copies the current configuration file onto the TFTP server. The syntax for the `copy config tftp` command is:

```
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy config tftp` command is in the `privExec` command mode.

[Table 23](#) describes the parameters and variables for the `copy config tftp` command.

Table 23 copy config tftp command parameters and variables

Parameters and variables	Description
address	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Specifies that you want to copy the configuration file onto the TFTP server. Enter the name you want the configuration file to have on the TFTP server.

copy tftp config command

The `copy tftp config` command retrieves the system configuration file from the TFTP server and uses the retrieved information as the current configuration on the system. The syntax for the `copy tftp config` command is:

```
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>
```

The `copy tftp config` command is in the `privExec` command mode.

[Table 24](#) describes the parameters and variables for the `copy tftp config` command.

Table 24 copy tftp config command parameters and variables


Parameters and variables	Description
address <XXX.XXX.XXX.XXX>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Enter the name of the configuration file you want to copy from the TFTP server.

Upgrading images

You can upgrade the software image and the diagnostics image from the TFTP server.

download command

The `download` command upgrades the software for the BPS 2000. You can upgrade both the software image and the diagnostics image. If you upgrade to a stack configuration, the entire stack will be upgraded, and the new image is loaded onto every unit of the stack.



Note: The system resets after downloading a new image.

The syntax for the `download` command is:

```
download [address <ip>] {image <image-name> [bs450-image
<image-name>] |diag <filename>}
```

The `download` command is in the `privExec` command mode.

[Table 25](#) describes the parameters and variables for the `download` command.


Table 25 download command parameters and variables

Parameters and variables	Description
address <ip>	Specifies the TFTP server you want to use. Note: If this parameter is omitted, the system goes to the server specified by the <code>tftp-server</code> command.
image <image-name>	Enter the name of the BPS 2000 software image you want to download.

Table 25 download command parameters and variables

Parameters and variables	Description
bs450-image <image-name>	Enter the name of the BayStack 450 software image you want to download.
diag <filename>	Enter the name of the BPS 2000 diagnostics image you want to download.

The system returns a message after successfully downloading a new image. [Figure 16](#) displays a sample output of the download command.

Figure 16 download message

```
Download Image [/]
Saving Image [-]
Finishing Upgrading Image
```

Displaying interfaces

You can view the status of all interfaces on the switch or stack, including MultiLink Trunk membership, link status, autonegotiation, and speed.

show interfaces command

The `show interfaces` command displays the current configuration and status of all interfaces. The syntax for the `show interfaces` command is:

```
show interfaces
```

The `show interfaces` command is in the exec command mode.

The `show interfaces` command has no parameters or variables.

[Figure 17](#) displays a sample output of the `show interfaces` command.

Figure 17 show interfaces command output

```

BPS2000#show interfaces
Port Trunk Status Link LinkTrap Autonegotiation Speed Duplex
-----
1      enable Down On      Enabled      100Mbs/Full
2      enable Up   On      Enabled      100Mbs/Full
3      enable Down On      Enabled      100Mbs/Full
4      enable Down On      Enabled      100Mbs/Full
5      enable Down On      Enabled      100Mbs/Full
6      enable Down On      Enabled      100Mbs/Full
7      enable Down On      Enabled      100Mbs/Full
8      enable Down On      Enabled      100Mbs/Full
9      enable Down On      Enabled      100Mbs/Full
10     enable Down On      Enabled      100Mbs/Full
11     enable Down On      Enabled      100Mbs/Full
12     enable Down On      Enabled      100Mbs/Full
13     enable Down On      Enabled      100Mbs/Full
14     enable Down On      Enabled      100Mbs/Full
15     enable Down On      Enabled      100Mbs/Full
16     disableDown On      Enabled      100Mbs/Full
17     enable Down On      Enabled      100Mbs/Full
18     enable Down On      Enabled      100Mbs/Full
19     enable Down On      Enabled      100Mbs/Full
20     enable Down On      Enabled      100Mbs/Full
21     enable Down On      Enabled      100Mbs/Full
22     enable Down On      Enabled      100Mbs/Full
23     enable Down On      Enabled      100Mbs/Full
24     enable Down On      Enabled      100Mbs/Full

```

Setting SNMP parameters

You can set various SNMP parameters and traps, as well as disable SNMP traps. This section covers:

- [“snmp-server command,”](#) next
- [“no snmp-server command”](#) on page 79
- [“snmp trap link-status command”](#) on page 80
- [“no snmp trap link-status command”](#) on page 80
- [“default snmp trap link-status command”](#) on page 81

snmp-server command

The `snmp-server` command configures various SNMP parameters. The syntax for the `snmp-server` command is:

```
snmp-server {{enable|disable}|authentication-trap|community
<community-string> [ro|rw] contact <text>|host <host-ip>
<community-string>|location <text>|name <text>}
```

The `snmp-server` command is in the config command mode.

[Table 26](#) describes the parameters and variables for the `snmp-server` command.

Table 26 snmp-server command parameters and variables

Parameters and variables	Description
authentication-trap	Enables generation of SNMP authentication failure traps.
community <community-string>	Changes the read-only (ro) or read-write (rw) community strings for SNMP v1 and SNMPv2c access. Enter a community string that works as a password and permits access to the SNMP protocol.
ro rw	Specifies read-only or read-write access. Stations with ro access can only retrieve MIB objects, and stations with rw access can retrieve and modify MIB objects. Note: If neither ro nor rw is specified, ro is assumed (default).
contact <text>	Specifies the SNMP sysContact value; enter an alphanumeric string.
host <host-ip> <community-string>	Configures an SNMP trap destination: <ul style="list-style-type: none">• host-ip—enter a dotted-decimal IP address of a host that will be the trap destination• community-string—enter a community string that works as a password and permits access to the SNMP protocol
location <text>	Specifies the SNMP sysLocation value; enter an alphanumeric string.
name <text>	Specifies the SNMP sysName value; enter an alphanumeric string.

no snmp-server command

The `no snmp-server` command disables SNMP or clears the configuration. If you omit the parameters, this command disables SNMP access. The syntax for the `no snmp-server` command is:

```
no snmp-server [authentication-trap|community [ro|rw]
contact|host [<host-ip> <community-string>]|location |name]
```

The `no snmp-server` command is in the config command mode.

[Table 27](#) describes the parameters and variables for the `snmp-server` command.

Table 27 no snmp-server command parameters and variables

Parameters and variables	Description
enable disable	With no parameters, disables SNMP access.
authentication-trap	Disables authentication failure traps.
community	Disables the community string.
ro rw	Disables either read-only or read-write access.
contact <text>	Clears the SNMP sysContact value.
host <host-ip> <community-string>	Removes an SNMP trap destination or all destinations.
location	Clears the SNMP sysLocation value.
name	Clears the SNMP sysName value



Note: Disabling SNMP access will also lock you out of the DM management system.

snmp trap link-status command

The `snmp trap link-status` command enables the linkUp/linkDown traps for the port. The syntax of the command is:

```
snmp trap link-status [port <portnum|all>]
```

The `snmp trap link-status` command is in the config-if command mode.

[Table 28](#) describes the parameters and variables for the `snmp trap link-status` command.

Table 28 snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portnum all>	Specifies the port number to enable the linkUp/linkDown traps on. Enter the port number or all. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

no snmp trap link-status command

The `no snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
no snmp trap link-status [port <portnum|all>]
```

The `no snmp trap link-status` command is in the config-if command mode.

[Table 29](#) describes the parameters and variables for the `no snmp trap link-status` command.

Table 29 no snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portnum all>	Specifies the port number to disable the linkUp/linkDown traps on. Enter the port number or all. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

default snmp trap link-status command

The `default snmp trap link-status` command disables the linkUp/linkDown traps for the port. The syntax of the command is:

```
default snmp trap link-status [port <portnum|all>]
```

The `default snmp trap link-status` command is in the config-if command mode.

[Table 30](#) describes the parameters and variables for the `default snmp trap link-status` command.

Table 30 default snmp trap link-status command parameters and variables

Parameters and variables	Description
port <portnum all>	Specifies the port number to disable the linkUp/linkDown traps on. Enter the port number or all. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

Setting the system event log

You can set the system event log to log different levels of events. This section covers:

- [“show logging,” next](#)
- [“set logging” on page 83](#)
- [“no set logging” on page 84](#)
- [“default set logging” on page 84](#)
- [“clear logging command” on page 84](#)

show logging

The `show logging` command displays the current contents of the system event log. The syntax for the `show logging` command is:

```
show logging [critical] [serious] [informational]
```

The `show logging` command is in the `privExec` command mode.

[Table 31](#) describes the parameters and variables for the `show logging` command.

Table 31 show logging command parameters and variables

Parameters and variables	Description
critical	Displays critical log messages.
serious	Displays serious log messages.
informational	Displays informational log messages.

[Figure 18](#) shows the output of the `show logging informational` command.

Figure 18 show logging command output

```

BPS2000#show logging informational
Type Unit Time Index Src Message
-----
I 1 00:00:01:52 1 Warm Start Trap
I 1 00:00:01:52 2 Enterprise Specific Trap
I 1 00:00:01:57 3 Link Up Trap
I 1 00:00:01:57 4 Link Up Trap
I 1 00:00:01:57 5 Link Up Trap
I 1 00:00:01:57 6 Link Up Trap

```

set logging

The `set logging` command configures the system settings for the system event log. The syntax for the `set logging` command is:

```

set logging [enable|disable] [level
critical|serious|informational] [nv-level
critical|serious|informational|none]

```

The `set logging` command is in the config command mode.

[Table 32](#) describes the parameters and variables for the `set logging` command.

Table 32 set logging command parameters and values

Parameters and variables	Description
enable disable	Enables or disables the event log (default is enabled).
level critical serious informational	Specifies the level of logging stored in DRAM.
nv-level critical serious informational none	Specifies the level of logging stored in NVRAM.

no set logging

The `no set logging` command disables the system event log. The syntax for the `no set logging` command is:

```
no set logging
```

The `no set logging` command is in the `config` command mode.

The `no set logging` command has no parameters or values.

default set logging

The `default set logging` command configures the system settings as the factory default settings for the system event log. The syntax for the `default set logging` command is:

```
default set logging
```

The `default set logging` command is in the `config` command mode.

The `default set logging` command has no parameters or values.

clear logging command

The `clear logging` command clears all log messages in DRAM. The syntax for the `clear logging` command is:

```
clear logging [nv]
```

The `clear logging` command is in the `privExec` command mode.

[Table 33](#) shows the parameters and values for the `clear logging` command.

Table 33 clear logging command parameters and values

Parameters and values	Description
nv	Clears all log messages in both DRAM and NVRAM.

Displaying port statistics

You can display the statistics for a port for both received and transmitted traffic. This section covers:

- [“show port-statistics command,”](#) next
- [“clear-stats command”](#) on page 87

show port-statistics command

The `show port-statistics` command displays the statistics for the port on both received and transmitted traffic. The syntax for the `show port-statistics` command is:

```
show port-statistics [port <portnum>]
```

The `show port-statistics` command is in the config-if command mode.

[Table 34](#) describes the parameters and variables for the `show port-statistics` command.

Table 34 show port-statistics command parameters and variables

Parameters and variables	Description
port <portnum>	<p>Specifies the port number to configure to display statistics on; enter the port number.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

Figure 19 displays sample output from the `show port-statistics` command.

Figure 19 show port-statistics command output

```
BPS2000(config-if)#show port-statistics
Received
  Packets:                0
  Multicasts:             0
  Broadcasts:             0
  TotalOctets:            0
  Lost Packets:           0
  Packets 64 bytes:       0
    65-127 bytes:         0
    128-255 bytes:        0
    256-511 bytes:        0
    512-1023 bytes:       0
    1024-1518 bytes:      0
  FCS Errors:             0
  Undersized Packets:     0
  Oversized Packets:      0
  Filtered Packets:       0
  Flooded PAKets:         0
  Frame Errors:           0
Transmitted
  Packets:                0
  Multicasts:             0
  Broadcasts:             0
  TotalOctets:            0
  Packets 64 bytes:       0
    65-127 bytes:         0
    128-255 bytes:        0
    256-511 bytes:        0
    512-1023 bytes:       0
    1024-1518 bytes:      0
  Collisions:             0
  Single Collisions:      0
  Multiple Collisions:    0
  Excessive Collisions:   0
  Deferred Packets:       0
  Late Collisions:        0
```

clear-stats command

The `clear-stats` command clears all statistical information for the specified port. All counters are set to zero (0). The syntax for the `clear-stats` command is:

```
clear-stats [port <portnum>]
```

The `clear-stats` command is in the config-if command mode.

[Table 35](#) describes the parameters and variables for the `clear-stats` command.

Table 35 clear-stats command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to clear of statistical information; enter the port number. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

Enabling or disabling a port

You can enable or disable a port using the CLI. This section covers the following commands:

- [“shutdown command,”](#) next
- [“no shutdown command”](#) on page 88

shutdown command

The `shutdown` command disables the port. The syntax for the `shutdown` command is:

```
shutdown [port <portnum>]
```

The `shutdown` command is in the `config-if` command mode.

[Table 36](#) describes the parameters and variables for the `shutdown` command.

Table 36 shutdown command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to shut down or disable. Enter the port number you want to disable. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

no shutdown command

The `no shutdown` command enables the port. The syntax for the `no shutdown` command is:

```
no shutdown [port <portnum>]
```

The `no shutdown` command is in the `config-if` command mode.

[Table 36](#) describes the parameters and variables for the `no shutdown` command.

Table 37 no shutdown command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to enable. Enter the port number you want to disable. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

Setting port speed

You can set the speed and duplex mode for a port. This section covers:

- “[speed command](#),” next
- “[default speed command](#)” on page 90
- “[duplex command](#)” on page 90
- “[default duplex command](#)” on page 91

speed command

The speed command sets the speed of the port. The syntax for the speed command is:

```
speed [port <portnum|all>] {10|100|1000|auto}
```

The speed command is in the config-if command mode.

[Table 38](#) describes the parameters and variables for the speed command.

Table 38 speed command parameters and variables

Parameters and variables	Description
port <portnum all>	<p>Specifies the port number to configure the speed. Enter the port number you want to configure, or all to configure all ports simultaneously.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>
10 100 1000 auto	<p>Sets speed to:</p> <ul style="list-style-type: none">• 10—10 Mb/s• 100—100 Mb/s• 1000—1000 Mb/s or 1 GB/s• auto—autonegotiation



Note: When you set the port speed for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

default speed command

The `default speed` command sets the speed of the port to the factory default speed. The syntax for the `default speed` command is:

```
default speed [port <portnum|all>]
```

The `default speed` command is in the config-if command mode.

[Table 38](#) describes the parameters and variables for the `default speed` command.

Table 39 default speed command parameters and variables

Parameters and variables	Description
port <portnum all>	<p>Specifies the port number to set the speed to factory default. Enter the port number you want to set, or all to set all ports simultaneously.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

duplex command

The `duplex` command specifies the duplex operation for a port. The syntax for the `duplex` command is:

```
duplex [port <portnum|all>] {full|half|auto}
```

The `duplex` command is in the config-if command mode.

Table 40 describes the parameters and variables for the `duplex` command.

Table 40 duplex command parameters and variables

Parameters and variables	Description
port <portnum all>	Specifies the port number to configure the duplex mode. Enter the port number you want to configure, or all to configure all ports simultaneously. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
full half auto	Sets duplex to: <ul style="list-style-type: none">• full—full-duplex mode• half—half-duplex mode• auto—autonegotiation



Note: When you set the duplex mode for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

default duplex command

The `default duplex` command sets the duplex operation for a port to the factory default duplex value. The syntax for the `default duplex` command is:

```
default duplex [port <portnum|all>]
```

The `default duplex` command is in the `config-if` command mode.

Table 40 describes the parameters and variables for the `default duplex` command.

Table 41 default duplex command parameters and variables

Parameters and variables	Description
port <portnum all>	<p>Specifies the port number to reset the duplex mode to factory default values. Enter the port number you want to configure, or all to configure all ports simultaneously. The default value is autonegotiation.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

Enabling Autopology

You can enable the Optivity* Autopology* protocol using the CLI. Refer to the www.nortelnetworks.com/documentation URL for information on Autopology. (The product family for Optivity and Autotopology is Data and Internet.). This section covers the following commands:

- “[autotopology command](#),” next
- “[no autotopology command](#)” on page 93
- “[default autotopology command](#)” on page 93

autotopology command

The `autotopology` command enables the Autotopology protocol. The syntax for the `autotopology` command is:

```
autotopology
```

The `autotopology` command is in the `config` command mode.

The `autotopology` command has no parameters or values.

no autotopology command

The `no autotopology` command disables the Autotopology protocol. The syntax for the `no autotopology` command is:

```
no autotopology
```

The `no autotopology` command is in the config command mode.

The `no autotopology` command has no parameters or values.

default autotopology command

The `default autotopology` command enables the Autotopology protocol. The syntax for the `default autotopology` command is:

```
default autotopology
```

The `default autotopology` command is in the config command mode.

The `default autotopology` command has no parameters or values.

Enabling flow control

If you use a Gigabit Ethernet MDA with the BPS 2000, you control traffic on this port using the `flowcontrol` command. This section covers the following commands:

- [“flowcontrol command,” next](#)
- [“no flowcontrol command” on page 94](#)
- [“default flowcontrol command” on page 95](#)

flowcontrol command

The `flowcontrol` command is used only on Gigabit Ethernet ports and controls the traffic rates during congestion. The syntax for the `flowcontrol` command is:

```
flowcontrol [port <portnum>]
{asymmetric|symmetric|auto|disable}
```

The `flowcontrol` command is in the config-if mode.

[Table 42](#) describes the parameters and variables for the `flowcontrol` command.

Table 42 flowcontrol command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to configure for flow control. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.
asymmetric symmetric auto disable	Sets the mode for flow control: <ul style="list-style-type: none">asymmetric—enables the local port to perform flow control on the remote portsymmetric—enables the local port to perform flow controlauto—sets the port to automatically determine the flow control mode (default)disable—disables flow control on the port

no flowcontrol command

The `no flowcontrol` command is used only on Gigabit Ethernet ports and disables flow control. The syntax for the `no flowcontrol` command is:

```
no flowcontrol [port <portnum>]
```

The `no flowcontrol` command is in the config-if mode.

[Table 43](#) describes the parameters and variables for the `no flowcontrol` command.

Table 43 no flowcontrol command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to disable flow control. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

default flowcontrol command

The `default flowcontrol` command is used only on Gigabit Ethernet ports and sets the flow control to auto, which automatically detects the flow control. The syntax for the `default flowcontrol` command is:

```
default flowcontrol [port <portnum>]
```

The `default flowcontrol` command is in the config-if mode.

[Table 43](#) describes the parameters and variables for the `default flowcontrol` command.

Table 44 default flowcontrol command parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the port number to default to auto flow control. Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.

Enabling rate-limiting

You can limit the percentage of multicast traffic, or broadcast traffic, or both using the CLI. For more information on rate-limiting, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

This section covers:

- [“show rate-limit command,” next](#)
- [“rate-limit command” on page 97](#)
- [“no rate-limit command” on page 98](#)
- [“default rate-limit command” on page 99](#)

show rate-limit command

The `show rate-limit` command displays the rate-limiting settings and statistics. The syntax for the `show rate-limit` command is:

```
show rate-limit
```

The `show rate-limit` command is in the `privExec` command mode.

The `show rate-limit` command has no parameters or variables.

[Figure 20](#) displays sample output from the `show rate-limit` command.

Figure 20 show rate-limit command output

BPS2000#show rate-limit

Unit/Port	Packet Type	Limit	Last 5 Minutes	Last Hour	Last 24 Hours
1/1	None	0%	0.0%	0.0%	0.0%
1/2	None	0%	0.0%	0.0%	0.0%
1/3	None	0%	0.0%	0.0%	0.0%
1/4	None	0%	0.0%	0.0%	0.0%
1/5	None	0%	0.0%	0.0%	0.0%
1/6	None	0%	0.0%	0.0%	0.0%
1/7	None	0%	0.0%	0.0%	0.0%
1/8	None	0%	0.0%	0.0%	0.0%
1/9	None	0%	0.0%	0.0%	0.0%
1/10	None	0%	0.0%	0.0%	0.0%
1/11	None	0%	0.0%	0.0%	0.0%
1/12	None	0%	0.0%	0.0%	0.0%
1/13	None	0%	0.0%	0.0%	0.0%
1/14	None	0%	0.0%	0.0%	0.0%
1/15	None	0%	0.0%	0.0%	0.0%
1/16	None	0%	0.0%	0.0%	0.0%

rate-limit command

The rate-limit command configures rate-limiting on the port. The syntax for the rate-limit command is:

```
rate-limit [port <portnum>] {multicast <pct>|broadcast <pct>|both <pct>}
```

The rate-limit command is in the config-if command mode.

[Table 45](#) describes the parameters and variables for the rate-limit command.

Table 45 rate-limit command parameters and variables

Parameters and values	Description
port <portnum>	<p>Specifies the port number to configure for rate-limiting. Enter the port number you want to configure.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>
multicast <pct> broadcast <pct> both <pct>	<p>Applies rate-limiting to the type of traffic. Enter an integer between 1 and 10 to set the rate-limiting percentage:</p> <ul style="list-style-type: none">• multicast—applies rate-limiting to multicast packets• broadcast—applies rate-limiting to broadcast packets• both—applies rate-limiting to both multicast and broadcast packets

no rate-limit command

The `no rate-limit` command disables rate-limiting on the port. The syntax for the `no rate-limit` command is:

```
no rate-limit [port <portnum>]
```

The `no rate-limit` command is in the config-if command mode.

[Table 46](#) describes the parameters and variables for the `no rate-limit` command.

Table 46 no rate-limit command parameters and variables

Parameters and variables	Description
port <portnum>	<p>Specifies the port number to disable for rate-limiting. Enter the port number you want to disable.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

default rate-limit command

The `default rate-limit` command restores the rate-limiting value for the specified port to the default setting. The syntax for the `default rate-limit` command is:

```
default rate-limit [port <portnum>]
```

The `default rate-limit` command is in the `config-if` command mode.

[Table 47](#) describes the parameters and variables for the `default rate-limit` command.

Table 47 default rate-limit command parameters and variables

Parameters and variables	Description
port <portnum>	<p>Specifies the port number to reset rate-limiting to factory default. Enter the port number you want to set rate-limiting to default on.</p> <p>Note: If you omit this parameter, the system uses the port number you specified in the <code>interface</code> command.</p>

Chapter 3

Security

This chapter describes the security commands available with the CLI. There are four types of security available on the BPS 2000:

- [“Using the IP manager list,” next](#)
- [“Using MAC address security” on page 106](#)
- [“Using EAPOL-based security” on page 112](#)
- [“Using RADIUS authentication” on page 115](#)

Refer to *Using the Business Policy Switch 2000 Software Version 1.2* for more information on these security features, as well as using the console interface (CI) menus. Refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* for information on configuring these features using the Web-based management system, and refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2* for information on configuring with the DM.

Using the IP manager list

When enabled, the IP manager list determines which source IP addresses are allowed access to the BPS 2000. No other source IP addresses have access to the switch. You configure the IP manager list using the following commands:

- [“show ipmgr command,” next](#)
- [“ipmgr command for management system” on page 103](#)
- [“no ipmgr command for management system” on page 104](#)
- [“ipmgr command for source IP address” on page 105](#)
- [“no ipmgr command for source IP address” on page 105](#)

show ipmgr command

The `show ipmgr` command displays whether Telnet, SNMP, and Web access are enabled; whether the IP manager list is being used to control access to Telnet, SNMP, and the Web-based management system; and the current IP manager list configuration. The syntax for the `show ipmgr` command is:

```
show ipmgr
```

The `show ipmgr` command is in the `privExec` command mode.

The `show ipmgr` command has no parameters or variables.

[Figure 21](#) displays sample output from the `show ipmgr` command.

Figure 21 show ipmgr command output

```

BPS2000#show ipmgr
TELNET Access: Enabled
SNMP Access:   Enabled
WEB Access:    Enabled
TELNET IP List Access Control: Enabled
SNMP IP List Access Control:   Enabled
WEB IP List Access Control:    Enabled
Allowed Source IP Address  Allowed Source Mask
-----
0.0.0.0                    0.0.0.0
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255
255.255.255.255           255.255.255.255

```

ipmgr command for management system

The `ipmgr` command for the management systems enables the IP manager list for Telnet, SNMP, or HTTP access. The syntax for the `ipmgr` command for the management systems is:

```
ipmgr {telnet|snmp|http}
```

The `ipmgr` command for the management systems is in the config mode.

[Table 48](#) describes the parameters and variables for the `ipmgr` command.

Table 48 ipmgr command for system management parameters and variables

Parameters and variables	Description
telnet snmp web	Enables IP manager list checking for access to various management systems: <ul style="list-style-type: none">• telnet—provides list access using Telnet access• snmp—provides list access using SNMP, including the DM• web—provides list access using the Web-based management system

no ipmgr command for management system

The `no ipmgr` command disables the IP manager list for Telnet, SNMP, or HTTP access. The syntax for the `no ipmgr` command for the management systems is:

```
no ipmgr {telnet|snmp|http}
```

The `no ipmgr` command is in the config mode.

[Table 49](#) describes the parameters and variables for the `no ipmgr` command.

Table 49 no ipmgr command for management system parameters and variables

Parameters and variables	Description
telnet snmp web	Disables IP manager list checking for access to various management systems: <ul style="list-style-type: none">• telnet—disables list check for Telnet access• snmp—disables list check for SNMP, including the DM• web—disables list check for the Web-based management system

ipmgr command for source IP address

The `ipmgr` command for source IP addresses allows you to enter the source IP addresses or address ranges that you allow to access the switch or the stack. The syntax for the `ipmgr` command for source IP addresses is:

```
ipmgr {source-ip <1-10> <XXX.XXX.XXX.XXX> [mask
<XXX.XXX.XXX.XXX>]}
```

The `ipmgr` command for the source IP addresses is in the config mode

[Table 48](#) describes the parameters and variables for the `ipmgr` command for the source IP addresses

Table 50 ipmgr command for source IP addresses parameters and variables

Parameters and variables	Description
source-ip <1-10> <XXX.XXX.XXX.XXX>[mask <XXX.XXX.XXX.XXX>]	Specifies the source IP address from which access is allowed. Enter the IP address either as an integer or in dotted-decimal notation. Specifies the subnet mask from which access is allowed; enter IP mask in dotted-decimal notation.

no ipmgr command for source IP address

The `no ipmgr` command for source IP addresses disables access for the specified source IP addresses or address ranges and denies them access to the switch or the stack. The syntax for the `no ipmgr` command for source IP addresses is:

```
no ipmgr {source-ip [<1-10>]}
```

The `no ipmgr` command for the source IP addresses is in the config mode

[Table 51](#) describes the parameters and variables for the `no ipmgr` command for the source IP addresses.

Table 51 no ipmgr command for source IP addresses parameters and variables

Parameters and variables	Description
source-ip [<1-10>]	When you specify an option, it sets the IP address and mask for the specified entry to 255.255.255.255 and 255.255.255.255. When you omit the optional parameter, it resets the list to factory defaults.

Using MAC address security

You configure the BaySecure* application using MAC addresses with the following commands:

- [“show mac-security command,” next](#)
- [“mac-security command” on page 107](#)
- [“mac-security mac-address-table address command” on page 108](#)
- [“mac-security security-list command” on page 109](#)
- [“no mac-security command” on page 110](#)
- [“no mac-security mac-address-table command” on page 110](#)
- [“no mac-security security-list command” on page 111](#)
- [“mac-security command for a specific port” on page 111](#)

show mac-security command

The `show mac-security` command displays configuration information for the BaySecure application. The syntax for the `show mac-security` command is:

```
show mac-security {config|mac-address-table [address  
<macaddr>] |port|security-lists}
```

The `show mac-security` command is in the `privExec` command mode.

[Table 52](#) describes the parameters and variables for the `show mac-security` command.

Table 52 show mac-security command parameters and variables

Parameters and variables	Description
config	Displays general BaySecure configuration.
mac-address-table [address <macaddr>]	Displays contents of BaySecure table of allowed MAC addresses: <ul style="list-style-type: none"> address—specifies a single MAC address to display; enter the MAC address
port	Displays the BaySecure status of all ports.
security-lists	Displays port membership of all security lists.

Figure 22 displays sample output from the `show mac-security` command.

Figure 22 show mac-security command output

```
BPS2000#show mac-security config
MAC Address Security: Disabled
MAC Address Security SNMP-Locked: Disabled
Partition Port on Intrusion Detected: Disabled
DA Filtering on Intrusion Detected: Disabled
Generate SNMP Trap on Intrusion: Disabled
Current Learning Mode: Disabled
Learn by Ports:
```

mac-security command

The `mac-security` command modifies the BaySecure configuration. The syntax for the `mac-security` command is:

```
mac-security [disable|enable] [filtering {enable|disable}]
[intrusion-detect {enable|disable|forever}] [intrusion-timer
<1-65535>] [learning-ports <portlist>] [learning
{enable|disable}] [snmp-lock {enable|disable}] [snmp-trap
{enable|disable}]
```

The `mac-security` command is in the `config` command mode.

[Table 53](#) describes the parameters and variables for the `mac-security` command.

Table 53 `mac-security` command parameters and values

Parameters and variables	Description
<code>disable enable</code>	Disables or enables MAC address-based security.
<code>filtering {enable disable}</code>	Enables or disables destination address (DA) filtering on intrusion detected.
<code>intrusion-detect {enable disable forever}</code>	Specifies partitioning of a port when an intrusion is detected: <ul style="list-style-type: none"> • <code>enable</code>—port is partitioned for a period of time • <code>disabled</code>—port is not partitioned on detection • <code>forever</code>—port is partitioned until manually changed
<code>intrusion-timer <1-65535></code>	Specifies, in seconds, length of time a port is partitioned when an intrusion is detected; enter the number of you want.
<code>learning-ports <portlist></code>	Specifies MAC address learning. Learned addresses are added to the table of allowed MAC addresses. Enter the ports you want to learn; it can be a single port, a range of ports, several ranges, all, or none.
<code>learning {enable disable}</code>	Specifies MAC address learning: <ul style="list-style-type: none"> • <code>enable</code>—enables learning by ports • <code>disable</code>—disables learning by ports
<code>snmp-lock {enable disable}</code>	Enables or disables a lock on SNMP write-access to the BaySecure MIBs.
<code>snmp-trap {enable disable}</code>	Enables or disables trap generation upon intrusion detection.

mac-security mac-address-table address command

The `mac-security mac-address-table address` command assigns either a specific port or a security list to the MAC address. This removes any previous assignment to the specified MAC address and creates an entry in the BaySecure table of allowed MAC addresses. The syntax for the `mac-security mac-address-table address` command is:

```
mac-security mac-address-table address <H.H.H.> {port
<portnum>|security-list <1-32>}
```

The `mac-security mac-address-table address` command is in the `config` command mode.

[Table 54](#) describes the parameters and variables for the `mac-security mac-address-table address` command.

Table 54 `mac-security mac-address-table address` command parameters and values

Parameters and variables	Description
<H.H.H>	Enter the MAC address in the form of H.H.H.
port <portnum> security-list <1-32>	Enter the port number or the security list number.

mac-security security-list command

The `mac-security security-list` command assigns a list of ports to a security list. The syntax for the `mac-security security-list` command is:

```
mac-security security-list <1-32> <portlist>
```

The `mac-security security-list` command is in the `config` command mode.

[Table 54](#) describes the parameters and variables for the `mac-security security-list` command.

Table 55 `mac-security security-list` command parameters and values

Parameters and variables	Description
<1-32>	Enter the number of the security list you want to use.
<portlist>	Enter a list or range of port numbers.

no mac-security command

The `no mac-security` command disables MAC source address-based security. The syntax for the `no mac-security` command is:

```
no mac-security
```

The `no mac-security` command is in the config command mode.

The `no mac-security` command has no parameters or values.

no mac-security mac-address-table command

The `no mac-security mac-address-table` command clears entries from the MAC address security table. The syntax for the `no mac-security mac-address-table` command is:

```
no mac-security mac-address-table {address <H.H.H.> |port  
<portlist>|security-list <1-32>}
```

The `no mac-security mac-address-table` command is in the config command mode.

[Table 54](#) describes the parameters and variables for the `no mac-security mac-address-table` command.

Table 56 no mac-security mac-address-table command parameters and values

Parameters and variables	Description
address <H.H.H>	Enter the MAC address in the form of H.H.H.
port <portlist>	Enter a list or range of port numbers.
security-list <1-32>	Enter the security list number.

no mac-security security-list command

The `no mac-security security-list` command clears the port membership of a security list. The syntax for the `no mac-security security-list` command is:

```
no mac-security security-list <1-32>
```

The `no mac-security security-list` command is in the config command mode.

[Table 57](#) describes the parameters and variables for the `no mac-security security-list` command.

Table 57 no mac-security security-list command parameters and values

Parameters and variables	Description
<1-32>	Enter the number of the security list you want to clear.

mac-security command for a specific port

The `mac-security` command for a single port configures the BaySecure status of a specific port. The syntax for the `mac-security` command for a single port is:

```
mac-security [port <portnum>] {disable|enable|learning}
```

The `mac-security` command for a single port is in the config-if command mode

[Table 58](#) describes the parameters and variables for the `mac-security` command for a single port.

Table 58 mac-security command for a single port parameters and variables

Parameters and variables	Description
port <portnum>	Enter a the port number.
disable enable learning	<p>Directs the specific port:</p> <ul style="list-style-type: none">• disable—disables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed• enable—enables BaySecure on the specified port and removes the port from the list of ports for which MAC address learning is being performed• learning—disables BaySecure on the specified port and adds these port to the list of ports for which MAC address learning is being performed

Using EAPOL-based security

You configure the security based on the Extensible Authentication Protocol over LAN (EAPOL) using the following CLI commands:

- [“show eapol command,”](#) next
- [“eapol command”](#) on page 113
- [“eapol command for modifying parameters”](#) on page 113

show eapol command

The `show eapol` command displays the status of the EAPOL-based security. The syntax for the `show eapol` command is:

```
show eapol
```

The `show eapol` command is in the `privExec` command mode.

The `show eapol` command has no parameters or variables.

The `show eapol` command displays the current status of the EAPOL parameters.

eapol command

The `eapol` command enables or disables EAPOL-based security. The syntax of the `eapol` command is:

```
eapol {disable|enable}
```

The `eapol` command is in the `config` command mode.

[Table 59](#) describes the parameters and variables for the `eapol` command.

Table 59 eapol command parameters and variables

Parameters and variables	Description
disable enable	Disables or enables EAPOL-based security.

eapol command for modifying parameters

The `eapol` command for modifying parameters modifies EAPOL-based security parameters for a specific port. The syntax of the `eapol` command for modifying parameters is:

```
eapol [port <portnum>] [init] [status  
authorized|unauthorized|auto] [traffic-control in-out|in]  
[re-authentication enable|disable]  
[re-authentication-interval <num>] [re-authenticate]  
[quiet-interval <num>] [transmit-interval <num>]  
[supplicant-timeout <num>] [server-timeout  
<num>] [max-request <num>]
```

The `eapol` command for modifying parameters is in the `config-if` command mode.

[Table 60](#) describes the parameters and variables for the `eapol` command for modifying parameters

Table 60 eapol command for modifying parameters and variables

Parameters and variables	Description
port <portnum>	Specifies the ports to configure for EAPOL; enter the port number you want. Note: If you omit this parameter, the system uses the port number specified when you issued the <code>interface</code> command.
init	Re-initiates EAP authentication.
status authorized unauthorized auto	Specifies the EAP status of the port: <ul style="list-style-type: none"> authorized—port is always authorized unauthorized—port is always unauthorized auto—port authorization status depends on the result of the EAP authentication
traffic-control in-outlin	Sets the level of traffic control: <ul style="list-style-type: none"> in-out—if EAP authentication fails, both ingressing and egressing traffic are blocked in—if EAP authentication fails, only ingressing traffic is blocked
re-authentication enable disable	Enables or disables re-authentication.
re-authentication-interval <num>	Enter the number of seconds you want between re-authentication attempts; range is 1 to 65535.
re-authenticate	Specifies an immediate re-authentication.
quiet-interval <num>	Enter the number of seconds you want between an authentication failure and the start of a new authentication attempt; range is 1 to 65535.
transmit-interval <num>	Specifies a waiting period for response from supplicant for EAP Request/Identity packets. Enter the number of seconds you want to wait; range is 1-65535.
supplicant-timeout <num>	Specifies a waiting period for response from supplicant for all EAP packets except EAP Request/Identity packets. Enter the number of seconds you want to wait; range is 1-65535.
server-timeout <num>	Specifies a waiting period for response from the server. Enter the number of seconds you want to wait; range is 1-65535
max-request <num>	Enter the number of times to retry sending packets to supplicant.

Using RADIUS authentication

Using a the RADIUS protocol and a server, you can configure the BPS 2000 for authentication. With the CLI system, you use the following commands:

- [“show radius-server command,”](#) next
- [“radius-server command”](#) on page 116
- [“no radius-server command”](#) on page 117

show radius-server command

The `show radius-server` command displays the RADIUS server configuration. The syntax for the `show radius-server` command is:

```
show radius-server
```

The `show radius-server` command is in the `privExec` command mode.

The `show radius-server` command has no parameters or variables.

[Figure 23](#) displays sample output from the `show radius-server` command.

Figure 23 show radius-server command output

```
BPS2000#show radius-server
host: 0.0.0.0
Secondary-host: 0.0.0.0
port: 1645
key:
BPS2000#
```

radius-server command

The `radius-server` command changes the RADIUS server settings. The syntax for the `radius-server` command is:

```
radius-server host <address> [secondary-host <address>] port
<num> key <string>
```

The `radius-server` command is in the config command mode.

[Table 61](#) describes the parameters and variables for the `radius-server` command.

Table 61 radius-server command parameters and variables

Parameters and variables	Description
host <address>	Specifies the primary RADIUS server. Enter the IP address of the RADIUS server.
secondary-host <address>	Specifies the secondary RADIUS server. Enter the IP address of the secondary RADIUS server.
port <num>	Enter the port number of the RADIUS server.
key <string>	Specifies a secret text string that is shared between the switch and the RADIUS server. Enter the secret string, which is an alphanumeric string up to 16 characters.

no radius-server command

The `no radius-server` command clears the RADIUS server settings. The syntax for the `no radius-server` command is:

```
no radius-server
```

The `no radius-server` command is in the config command mode.

The `no radius-server` command has no parameters or values.

Chapter 4

Spanning Tree, MLT, and Port-Mirroring

This chapter describes how to configure the Spanning Tree Protocol, spanning tree groups, Multi-Link Trunking (MLT), and port-mirroring. This chapter covers the following topics:

- [“Using spanning tree,”](#) next
- [“Using MLT”](#) on page 132
- [“Using port-mirroring”](#) on page 135

Refer to the *Using the Business Policy Switch 2000 Software Version 1.2* for more information on multiple spanning tree groups, spanning tree, MLT, and port-mirroring, as well as configuration directions using the console interface (CI) menus. Refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* for information on configuring these features using the Web-based management system, and refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2* for configuration information for the DM.

Using spanning tree



Note: For detailed information on spanning tree parameters, spanning tree groups, and configuration guidelines, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

With the BPS 2000 with software version 1.2, you can configure multiple spanning tree groups (STGs). (Multiple spanning tree groups are available only when the Stack Operational Mode is set to Pure BPS 2000 Stack.) The CLI allows you to configure spanning tree groups, to add or remove VLANs to the spanning tree groups, and to configure the usual spanning tree parameters and FastLearn. This section covers the following topics:

- [“show spanning-tree command,” next](#)
- [“spanning-tree stp create command by STG” on page 123](#)
- [“spanning-tree stp delete command by STG” on page 124](#)
- [“spanning-tree stp enable command by STG” on page 124](#)
- [“spanning-tree stp disable command by STG” on page 125](#)
- [“spanning-tree command by STG” on page 126](#)
- [“default spanning-tree command by STG” on page 127](#)
- [“spanning-tree add-vlan command” on page 127](#)
- [“spanning-tree remove-vlan command” on page 128](#)
- [“spanning-tree command by port” on page 129](#)
- [“default spanning-tree command by port” on page 130](#)
- [“no spanning-tree command by port” on page 131](#)



Note: When you omit the spanning tree group parameter (stp <1-8>) in the any of the spanning tree commands, the commands operate on the default spanning tree group (spanning tree group 1).

show spanning-tree command

The `show spanning-tree` command displays spanning tree configuration information that is specific to either the spanning tree group or to the port. The syntax for the `show spanning-tree` command is:

```
show spanning-tree [stp <1-8>] {config|port}
```

The `show spanning-tree` command is in the `privExec` command mode,

[Table 62](#) describes the parameters and variables for the `show spanning-tree` command.

Table 62 show spanning-tree command parameters and variables

Parameters and variables	Description
stp <1-8>	Displays specified spanning tree group configuration; enter the number of the group you want displayed.
config port	Displays spanning tree configuration for: <ul style="list-style-type: none">• config—the specified (or default) spanning tree group• port—the ports within the spanning tree group

[Figure 24](#) displays sample output from the `show spanning-tree` command for the default spanning tree group (STP1). [Figure 25](#) shows the spanning tree parameters by port.

Figure 24 show spanning-tree command output by port

```

BPS2000#show spanning-tree stp 1 port
Unit Port Trunk Participation Priority Path Cost State
-----
1 1 Normal Learning 128 10 Forwarding
1 2 Normal Learning 128 10 Forwarding
1 3 Normal Learning 128 10 Forwarding
1 4 Normal Learning 128 10 Forwarding
1 5 Normal Learning 128 10 Forwarding
1 6 Normal Learning 128 10 Forwarding
1 7 Normal Learning 128 10 Forwarding
1 8 Normal Learning 128 10 Forwarding
1 9 Normal Learning 128 10 Forwarding
1 10 Normal Learning 128 10 Forwarding
1 11 Normal Learning 128 10 Forwarding
1 12 Normal Learning 128 10 Forwarding
1 13 Normal Learning 128 10 Forwarding
1 14 Normal Learning 128 10 Forwarding
1 15 Normal Learning 128 10 Forwarding
1 16 Normal Learning 128 10 Forwarding
1 17 Normal Learning 128 10 Forwarding
1 18 Normal Learning 128 10 Forwarding
1 19 Normal Learning 128 10 Forwarding
1 20 Normal Learning 128 10 Forwarding
1 21 Normal Learning 128 10 Forwarding
1 22 Normal Learning 128 10 Forwarding
1 23 Normal Learning 128 10 Forwarding
1 24 Normal Learning 128 10 Forwarding

```

Figure 25 show spanning-tree command output for spanning tree group

```
BPS2000#show spanning-tree config
Bridge Priority:          8000
Designated Root:         8000000342f6de21
Root Port:               2
Root Path Cost:          30
Hello Time:               2 seconds
Maximum Age Time:        20 seconds
Forward Delay:           15 seconds
Bridge Hello Time:        2 seconds
Bridge Maximum Age Time: 20 seconds
Bridge Forward Delay:     15 seconds
```

spanning-tree stp create command by STG



Note: For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the Business Policy Switch 2000 Software Version 1.2*.

The `spanning-tree stp create` command allows you to create a spanning tree group. The syntax for the `spanning-tree stp create` command is:

```
spanning-tree stp <1-8> create
```

The `spanning-tree stp create` command is in the config command mode.

[Table 63](#) describes the parameters and variables for the `spanning-tree stp create` command.

Table 63 spanning-tree stp create command parameters and variables

Parameters and variables	Description
<1-8>	Enter the number of the spanning tree group you are creating (STG ID). You cannot create the default spanning tree group, which is number 1.

spanning-tree stp delete command by STG

The `spanning-tree stp delete` command allows you to delete a spanning tree group. The syntax for the `spanning-tree stp delete` command is:

```
spanning-tree stp <1-8> delete
```

The `spanning-tree stp delete` command is in the config command mode.

[Table 64](#) describes the parameters and variables for the `spanning-tree stp delete` command.

Table 64 spanning-tree stp delete command parameters and variables

Parameters and variables	Description
<1-8>	Enter the number of the spanning tree group you are deleting (STG ID). You cannot delete the default spanning tree group, which is number 1.

spanning-tree stp enable command by STG

The `spanning-tree stp enable` command allows you to enable a spanning tree group. The syntax for the `spanning-tree stp enable` command is:

```
spanning-tree stp <1-8> enable
```

The `spanning-tree stp enable` command is in the config command mode.

[Table 65](#) describes the parameters and variables for the `spanning-tree stp enable` command.

Table 65 spanning-tree stp enable command parameters and variables

Parameters and variables	Description
<1-8>	Enter the number of the spanning tree group you want to enable (STG ID). You cannot enable the default spanning tree group, which is number 1; it is always enabled.

spanning-tree stp disable command by STG

The `spanning-tree stp disable` command allows you to disable a spanning tree group. The syntax for the `spanning-tree stp disable` command is:

```
spanning-tree stp <1-8> disable
```

The `spanning-tree stp disable` command is in the config command mode.

[Table 66](#) describes the parameters and variables for the `spanning-tree stp disable` command.

Table 66 spanning-tree stp disable command parameters and variables

Parameters and variables	Description
<1-8>	Enter the number of the spanning tree group you want to disable (STG ID). You cannot disable the default spanning tree group, which is number 1d.

spanning-tree command by STG

The `spanning-tree` command by STG sets STP values by STG. The syntax for the `spanning-tree` command by STG is:

```
spanning-tree [stp <1-8>] [forward-time <4-30>] [hello-time  
<1-10>] [max-age <6-40>] [priority <0-65535>] [tagged-bpdu  
{enable|disable}]
```

The `spanning-tree` command by STG is in the config command mode.

[Table 67](#) describes the parameters and variables for the `spanning-tree` command by STG.

Table 67 spanning-tree command by STG parameters and variables

Parameters and variables	Description
stp <1-8>	Specifies the spanning tree group you want; enter the STG ID.
forward-time <4-30>	Enter the forward time of the STG in seconds; range is 4-30. Default value is 15.
hello-time <1-10>	Enter the hello time of the STG in seconds; range is 1-10. Default value is 2.
max-age <6-40>	Enter the max-age of the STG in seconds; range is 6-40. Default value is 20.
priority <0-65535>	Enter the priority of the STG in seconds; range is 0-65535. Default value is 0x8000.
tagged-bpdu {enable disable}	Allows you to set the BPDU as tagged or untagged. Default value for spanning tree group 1 (default group) is untagged; the default for the other groups is tagged.

default spanning-tree command by STG

The `default spanning-tree` command by STG restores the default spanning tree values for the spanning tree group. The syntax for the `default spanning-tree` command by STG is:

```
default spanning-tree [stp <1-8>] [forward-time]
[hello-time] [max-age] [priority] [tagged-bpdu]
```

The `default spanning-tree` command by STG is in the config command mode.

[Table 68](#) describes the parameters and variables for the `default spanning-tree` command by STG.

Table 68 default spanning-tree command by STG parameters and variables

Parameters and variables	Description
stp <1-8>	Disables the spanning tree group; enter the STG ID.
forward-time	Sets the forward time to default value—15 seconds.
hello-time	Sets the hello time to default value—2 seconds.
max-age	Sets the maximum age time to default value—20 seconds.
priority	Sets the priority to default value—0x8000.
tagged-bpdu	Sets the tagging to default value. Default value for spanning tree group 1 (default group) is untagged; the default for the other groups is tagged.

spanning-tree add-vlan command

The `spanning-tree add-vlan` command allows you to add a VLAN to a specified spanning tree group. The syntax for the `spanning-tree add-vlan` command is:

```
spanning-tree [stp <1-8>] add-vlan <1-4094>
```

The `spanning-tree add-vlan` command by port is in the config command mode.

[Table 69](#) describes the parameters and variables for the `spanning-tree add-vlan` command.

Table 69 spanning-tree add-vlan command parameters and variables

Parameters and variables	Description
stp <1-8>	Specifies the spanning tree group you want to add the VLAN to; enter the STG ID. Note: If you omit this parameter, the system uses the default spanning tree group, 1.
add-vlan <1-4094>	Enter the VLAN you want to add to the spanning tree group.



Note: VLAN 1 is always in spanning tree group 1.

spanning-tree remove-vlan command

The `spanning-tree remove-vlan` command allows you to remove a VLAN from a specified spanning tree group. The syntax for the `spanning-tree remove-vlan` command is:

```
spanning-tree [stp <1-8>] remove-vlan <1-4094>
```

The `spanning-tree remove-vlan` command by port is in the config command mode.

[Table 70](#) describes the parameters and variables for the `spanning-tree remove-vlan` command.

Table 70 spanning-tree remove-vlan command parameters and variables

Parameters and variables	Description
stp <1-8>	Specifies the spanning tree group you want to remove the VLAN from; enter the STG ID. Note: If you omit this parameter, the system uses the default spanning tree group, 1.
remove-vlan <1-4094>	Enter the VLAN you want to remove from the spanning tree group.



Note: You cannot remove VLAN 1 from spanning tree group 1.

spanning-tree command by port



Note: For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the Business Policy Switch 2000 Software Version 1.2*.

The `spanning-tree` command by port sets Spanning Tree Protocol (STP) and multiple spanning tree group (STG) participation for the ports within the specified spanning tree group. The syntax for the `spanning-tree` command by port is:

```
spanning-tree [port <portnum>] [stp <1-8>] [learning  
{disable|normal|fast}] [cost <1-65535>] [priority <0-255>]
```

The `spanning-tree` command by port is in the config-if command mode.

[Table 71](#) describes the parameters and variables for the `spanning-tree` command by port.

Table 71 spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portnum>	Enables spanning tree for the specified port or ports; enter port or ports you want enabled for spanning tree. Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
stp <1-8>	Specifies the spanning tree group you want; enter the STG ID.
learning {disable normal fast}	Specifies the STP learning mode: <ul style="list-style-type: none">• disable—disables FastLearn mode• normal—changes to normal learning mode• fast—enables FastLearn mode
cost <1-65535>	Enter the path cost of the spanning tree; range is 1-.65535.
priority <0-255>	Enter the priority value of the spanning tree; range is 0-255.

default spanning-tree command by port

The `default spanning-tree` command by port sets the spanning tree values for the ports within the specified spanning tree group to the factory default settings. The syntax for the `default spanning-tree` command by port is:

```
default spanning-tree [port <portnum>] [stp <1-8>]
[learning] [cost] [priority]
```

The `default spanning-tree` command by port is in the `config-if` command mode.

[Table 72](#) describes the parameters and variables for the `default spanning-tree` command by port.

Table 72 default spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portnum>	Enables spanning tree for the specified port or ports; enter port or ports you want set to factory spanning tree default values. Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
stp <1-8>	Specifies the spanning tree group you want to set to factory default value; enter the STG ID. This command places the port into the default STG. Default value for STG is 1.
learning	Sets the spanning tree learning mode to factory default value. Default value for learning is normal mode.
cost	Sets the path cost to factory default value. Default value for path cost depends on the type of port.
priority	Sets the priority to factory default value. Default value for the priority is 0x8000.

no spanning-tree command by port

The `no spanning-tree` command by port disables spanning tree for a port in a specific spanning tree group. The syntax for the `no spanning-tree` command by port is:

```
no spanning-tree [port <portnum>] [stp <1-8>]
```

The `no spanning-tree` command by port is in the config-if command mode.

[Table 73](#) describes the parameters and variables for the `no spanning-tree` command by port.

Table 73 no spanning-tree command by port parameters and variables

Parameters and variables	Description
port <portnum>	Disables spanning tree for the specified port or ports; enter port or ports you want enabled for STP. Note: If you omit this parameter, the system uses the port number you specified when you issued the <code>interface</code> command.
stp <1-8>	Disables the port in the specified spanning tree group; enter the STG ID.

Using MLT



Note: For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the Business Policy Switch 2000 Software Version 1.2*.

You configure Multi-Link Trunking (MLT) using the following commands:

- “[show mlt command](#),” next
- “[mlt command](#)” on page 133
- “[no mlt command](#)” on page 134

show mlt command

The `show mlt` command displays the Multi-Link Trunking (MLT) configuration and utilization. The syntax for the `show mlt` command is:

```
show mlt [utilization <1-6>]
```

The `show mlt` command is in the `privExec` command mode.

Table 74 describes the parameters and variables for the `show mlt` command.

Table 74 `show mlt` command parameters and variables

Parameters and variables	Description
utilization <1-6>	Displays the utilization of the specified enabled MLT(s) in percentages.

Figure 26 displays sample output from the `show mlt` command.

Figure 26 `show mlt` command output

```
BPS2000#show mlt
Trunk Name          Members      STP Learning    Mode  Status
-----
1      Trunk #1              Normal          Basic  Disabled
2      Trunk #2              Normal          Basic  Disabled
3      Trunk #3              Normal          Basic  Disabled
4      Trunk #4              Normal          Basic  Disabled
5      Trunk #5              Normal          Basic  Disabled
6      Trunk #6              Normal          Basic  Disabled
BPS2000#
```

mlt command

The `mlt` command configures a Multi-Link Trunk (MLT). The syntax for the `mlt` command is:

```
mlt <id> [name <trunkname>] [enable|disable] [member
<portlist>]
```

The `mlt` command is in the config command mode.

Table 75 describes the parameters and variables for the `mlt` command.

Table 75 mlt command parameters and variables

Parameters and variables	Description
id	Enter the trunk ID; range is 1 to 6.
name <trunkname>	Specifies a text name for the trunk; enter up to 16 alphanumeric characters.
enable disable	Enables or disables the trunk.
member <portlist>	Enter the ports that you want as members of the trunk.



Note: You can modify an MLT when it is enabled or disabled.

no mlt command

The `no mlt` command disables a Multi-Link Trunk (MLT), clearing all the port members. The syntax for the `no mlt` command is:

```
no mlt [<id>]
```

The `no mlt` command is in the `config` command mode.

[Table 76](#) describes the parameters and variables for the `no mlt` command.

Table 76 no mlt command parameters and variables

Parameters and variables	Description
<id>	Enter the trunk ID to disable the trunk and to clear the port members of the specified trunk.

Using port-mirroring

You use port-mirroring to monitor traffic. Refer to *Using the Business Policy Switch 2000 Software Version 1.2* for configuration guidelines for port-mirroring. This section covers the following commands:

- [“show port-mirroring command,”](#) next
- [“port-mirroring command”](#) on page 135
- [“no port-mirroring command”](#) on page 137

show port-mirroring command

The `show port-mirroring` command displays the port-mirroring configuration. The syntax for the `show port-mirroring` command is:

```
show port-mirroring
```

The `show port-mirroring` command is in the `privExec` command mode.

The `show port-mirroring` command has no parameters or variables.

[Figure 27](#) displays sample output from the `show port-mirroring` command.

Figure 27 show port-mirroring command output

```
BPS2000(config)#show port-mirroring
Monitoring Mode: Xrx ( -> Port X )
Monitor Port:    1/3
Port X:          1/1
```

port-mirroring command

The `port-mirroring` command sets the port-mirroring configuration. The syntax of the `port-mirroring` command is:

```

port-mirroring mode
{disable |
Xrx monitor-port <portnum> mirror-port-X <portnum>|
Xtx monitor-port <portnum> mirror-port-X <portnum>|
XrxOrXtx monitor-port <portnum> mirror-port-X <portnum>
mirror-port-Y <portnum>|
XrxOrYtx monitor-port <portnum> mirror-port-X <portnum>
mirror-port-Y <portnum>|
XrxYtx monitor-port <portnum> mirror-port-X <portnum>
mirror-port-Y <portnum>|
XrxYtxOrYrxXtx monitor-port <portnum> mirror-port-X
<portnum> mirror-port-Y <portnum>|
Asrc monitor-port <portnum> mirror-MAC-A <macaddr>|
Adst monitor-port <portnum> mirror-MAC-A <macaddr>|
AsrcOrAdst monitor-port <portnum> mirror-MAC-A <macaddr>|
AsrcBdst monitor-port <portnum> mirror-MAC-A <macaddr>
mirror-MAC-B <macaddr>|
AsrcBdstOrBsrcAdst monitor-port <portnum> mirror-MAC-A
<macaddr> mirror-MAC-B <macaddr>}

```

The `port-mirroring` command is in the `config` command mode.

[Table 77](#) describes the parameters and variables for the `port-mirroring` command.

Table 77 port-mirroring command parameters and variables

Parameters and variables	Description
disable	Disables port-mirroring.
monitor-port	Specifies the monitor port.
mirror-port-X	Specifies the mirroring port X.
mirror-port-Y	Specifies the mirroring port Y.
mirror-MAC-A	Specifies the mirroring MAC address A.
mirror-MAC-B	Specifies the mirroring MAC address B.
portnum	Enter the port number.
Xrx	Mirror packets received on port X.
Xtx	Mirror packets transmitted on port X.
XrxOrXtx	Mirror packets received or transmitted on port X.
XrxOrYtx	Mirror packets received on port X or transmitted on port Y.

Table 77 port-mirroring command parameters and variables

Parameters and variables	Description
XrxYtx	Mirror packets received on port X and transmitted on port Y.
XrxYtxOrXtxYrx	Mirror packets received on port X and transmitted on port Y or packets received on port Y and transmitted on port X.
macaddr	Enter the MAC address in format H.H.H.
Asrc	Mirror packets with source MAC address A.
Adst	Mirror packets with destination MAC address A.
AsrcOrAdst	Mirror packets with source or destination MAC address A.
AsrcBdst	Mirror packets with source MAC address A and destination MAC address B.
AsrcBdstOrBsrcAdst	Mirror packets with source MAC address A and destination MAC address B or packets with source MAC address B and destination MAC address A.

no port-mirroring command

The `no port-mirroring` command disables port-mirroring. The syntax of the `no port-mirroring` command is:

```
no port-mirroring
```

The `no port-mirroring` command is in the config command mode.

The `no port-mirroring` command has no parameters or variables.

Chapter 5

VLANs and IGMP

This chapter describes how to configure virtual LANs and IGMP snooping parameters. This chapter covers the following topics:

- [“Increased VLAN support,”](#) next
- [“Configuring and displaying VLANs”](#) on page 140
- [“Displaying multicast membership”](#) on page 152
- [“Using IGMP snooping”](#) on page 153

Refer to the *Using the Business Policy Switch 2000 Software Version 1.2* for more information on VLANs, IGMP snooping, and multicast groups, as well as configuration directions using the console interface (CI) menus. Refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* for information on configuring these features using the Web-based management system, and refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2* for configuration information for the DM.

Increased VLAN support

With software version 1.2, the BPS 2000 supports up to 256 VLANs. You can configure as many as 255 protocol-based VLANs, with up to 14 different protocols. To find out which version of the BPS 2000 software is running, use the `show sys-info` command in the `privExec` command mode. The software currently running is displayed in the `sysDescr` field.

You can use 256 port-, protocol-, and MAC SA-based VLANs for the stack with a Pure BPS 2000 stack running software version 1.2. (The maximum number of MAC SA-based VLANs available is 48). If you are working with a mixed, or hybrid, stack, you can use 64 VLANs for the entire stack. When you change from a Pure BPS 2000 Stack mode to a Hybrid Stack mode:

- If you have up to 64 VLANs on the Pure BPS 2000 Stack, they will be retained when you change to a Hybrid Stack.
- If you have more than 64 VLANs on the Pure BPS 2000 Stack, you will lose them all. The Hybrid Stack will return to the default VLAN configuration.

Also, a mixed, or hybrid, stack does not support multiple Spanning Tree Groups (STG). You have a single instance of STG when working with a mixed stack.



Note: Ensure that stack operational mode is set to Pure BPS 2000, and not Hybrid. The standalone or stack of BPS 2000 switches must be operating in Pure BPS 2000 Stack mode. Refer to Chapter 1 for information on displaying and setting the stack operational mode.

Configuring and displaying VLANs

You configure and display VLANs using a variety of command modes, depending on whether you are working with ports, protocol-based VLANs, or MAC source address-based VLANs. You can also enable or disable the automatic PVID feature. This section covers the following topics:

- “[show vlan interface info command](#),” next
- “[show vlan interface vids command](#)” on page 142
- “[vlan create command](#)” on page 143
- “[vlan delete command](#)” on page 146
- “[no vlan command](#)” on page 146v
- “[vlan name command](#)” on page 147
- “[auto-pvid command](#)” on page 147
- “[no auto-pvid command](#)” on page 147
- “[vlan ports command](#)” on page 148
- “[vlan members command](#)” on page 149
- “[show vlan mac-address command](#)” on page 150
- “[vlan mac-address command](#)” on page 151
- “[no vlan mac-address command](#)” on page 151

Refer to Appendix A for an alphabetical list of the VLAN commands.



Note: For guidelines for configuring VLANs, spanning tree groups, and MLTs, refer to Chapter 1 of the *Using the Business Policy Switch 2000 Software Version 1.2*.

show vlan interface info command

The `show vlan interface info` command displays VLAN settings associated with a port, including tagging information, PVID number, priority, and filtering information for tagged, untagged, and unregistered frames. The syntax for the `show vlan interface info` command is:

```
show vlan interface info [<portlist>]
```

The `show vlan interface info` command is in the `privExec` command mode.

[Table 78](#) describes the parameters and variables for the `show vlan interface info` command.

Table 78 show vlan command interface info parameters and variables

Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

[Figure 28](#) displays sample output from the `show vlan interface info` command.

Figure 28 show vlan interface info output

```

BPS2000(config-if)#show vlan interface info
      Filter   Filter   Filter
      Tagged  Untagged  Unregistered
Unit/Port  Frames   Frames   Frames   PVID Priority Tagging  Name
-----
1/1        No       No       No       1    0       Disabled Unit 1, Port 1
1/2        No       No       No       2    0       Disabled Unit 1, Port 2
1/3        No       No       No       1    0       Disabled Unit 1, Port 3
1/4        No       No       No       1    0       Disabled Unit 1, Port 4
1/5        No       No       No       1    0       Disabled Unit 1, Port 5
1/6        No       No       No       1    0       Disabled Unit 1, Port 6
1/7        No       No       No       1    0       Disabled Unit 1, Port 7
1/8        No       No       No       1    0       Disabled Unit 1, Port 8
1/9        No       No       No       1    0       Disabled Unit 1, Port 9
1/10       No       No       No       1    0       Disabled Unit 1, Port 10
1/11       No       No       No       1    0       Disabled Unit 1, Port 11
1/12       No       No       No       1    0       Disabled Unit 1, Port 12
1/13       No       No       No       1    0       Disabled Unit 1, Port 13
1/14       No       No       No       1    0       Disabled Unit 1, Port 14
1/15       No       No       No       1    0       Disabled Unit 1, Port 15
1/16       No       No       No       1    0       Disabled Unit 1, Port 16
1/17       No       No       No       1    0       Disabled Unit 1, Port 17
1/18       No       No       No       1    0       Disabled Unit 1, Port 18

```

show vlan interface vids command

The `show vlan interface vids` command displays port memberships in VLANs. The syntax for the `show vlan interface vids` command is:

```
show vlan interface vids [<portlist>]
```

The `show vlan interface vids` command is in the `privExec` command mode.


[Table 78](#) describes the parameters and variables for the `show vlan interface vids` command.

Table 79 show vlan command interface vids parameters and variables


Parameters and variables	Description
<portlist>	Enter the list of ports you want the VLAN information for, or enter all to display all ports.

Figure 29 displays sample output from the show vlan interface vids command.

Figure 29 show vlan interface vids output



vlan create command



Note: For guidelines for configuring STGs, VLANs, and MLTs, refer to Chapter 1 of the *Using the Business Policy Switch 2000 Software Version 1.2*.

The `vlan create` command allows you to create a VLAN. You create a VLAN by setting the state of a previously non-existent VLAN.



Note: With software version 1.2, you can configure as many as 255 protocol-based VLANs, with up to 14 different protocols.

The syntax for the `vlan create` command is:

```
vlan create <1-4094> [name <line>] [learning {IVL|SVL}]
type
{macsa|
port|
protocol-ipEther2|
protocol-ipx802.3|
protocol-ipx802.2|
protocol-ipxSnap|
protocol-ipxEther2|
protocol-ApltkEther2Snap|
protocol-decEther2|
protocol-decOtherEther2|
protocol-sna802.2|
protocol-snaEther2|
protocol-Netbios|
protocol-xnsEther2|
protocol-vinesEther2|
protocol-ipv6Ether2|
protocol-Userdef <4096-65534>|
protocol-RarpEther2|
[IVL|SVL] }
```

The `vlan create` command is in the config command mode.

[Table 80](#) describes the parameters and variables for the `vlan create` command.

Table 80 vlan create command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to create.
name <line>	Enter the name of the VLAN to create.

Table 80 vlan create command parameters and variables (continued)

Parameters and variables	Description
learning {IVL SVL}	Enter the type of learning you want for the VLAN: <ul style="list-style-type: none"> IVL—independent VLAN learning SVL—shared VLAN learning <p>Note: IVL is available <i>only</i> when you are operating in the Pure BPS 2000 stack mode.</p>
type	Enter the type of VLAN to create: <ul style="list-style-type: none"> macsa—MAC source address-based port—port-based protocol—protocol-based (see following list)
protocol-ipEther2	Specifies an ipEther2 protocol-based VLAN.
protocol-ipx802.3	Specifies an ipx802.3 protocol-based VLAN.
protocol-ipx802.2	Specifies an ipx802.2 protocol-based VLAN.
protocol-ipxSnap	Specifies an ipxSnap protocol-based VLAN.
protocol-ipxEther2	Specifies an ipxEther2 protocol-based VLAN.
protocol-ApltkEther2Snap	Specifies an ApltkEther2Sanp protocol-based VLAN.
protocol-decEther2	Specifies a decEther2 protocol-based VLAN.
protocol-decOtherEther2	Specifies a decOtherEther2 protocol-based VLAN.
protocol-sna802.2	Specifies an sna802.2 protocol-based VLAN.
protocol-snaEther2	Specifies an snaEther2 protocol-based VLAN.
protocol-Netbios	Specifies a NetBIOS protocol-based VLAN.
protocol-xnsEther2	Specifies an xnsEther2 protocol-based VLAN.
protocol-vinesEther2	Specifies a vinesEther2 protocol-based VLAN.
protocol-ipv6Ether2	Specifies an ipv6Ether2 protocol-based VLAN.
protocol-Userdef <4096-65534>	Specifies a user-defined protocol-based VLAN.
protocol-RarpEther2	Specifies an RarpEther2 protocol-based VLAN.



Note: This command fails if the VLAN already exists.

vlan delete command

The `vlan delete` command allows you to delete a VLAN. The syntax for the `vlan delete` command is:

```
vlan delete <1-4094>
```

The `vlan delete` command is in the config command mode.

[Table 80](#) describes the parameters and variables for the `vlan delete` command.

Table 81 vlan delete command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to delete.

no vlan command

The `no vlan` command allows you to delete a VLAN. The syntax for the `no vlan` command is:

```
no vlan <1-4094>
```

The `no vlan` command is in the config command mode.

[Table 80](#) describes the parameters and variables for the `no vlan` command.

Table 82 no vlan command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN to delete.

vlan name command

The `vlan name` command allows you to change the name of an existing VLAN. The syntax for the `vlan name` command is:

```
vlan name <1-4094> <line>
```

The `vlan name` command is in the config command mode.

[Table 80](#) describes the parameters and variables for the `vlan name` command.

Table 83 vlan name command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to change the name of.
<line>	Enter the new name you want for the VLAN.

auto-pvid command

The `auto-pvid` command allows you to enable the automatic PVID feature. The syntax for the `auto-pvid` command is:

```
auto-pvid
```

The `auto-pvid` command is in the config command mode.

The `auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

no auto-pvid command

The `no auto-pvid` command allows you to disable the automatic PVID feature. The syntax for the `no auto-pvid` command is:

```
no auto-pvid
```

The `no auto-pvid` command is in the config command mode.

The `no auto-pvid` command has no parameters or variables.

For more information on the automatic PVID feature, refer to *Using the Business Policy Switch 2000 Software Version 1.2*.

vlan ports command

The `vlan ports` command configures the VLAN-related settings for a port. The syntax for the `vlan ports` command is:

```
vlan ports [<portlist>] [tagging {enable|disable}]  
[pvid <1-4094>] [filter-tagged-frame {enable|disable}]  
[filter-untagged-frame {enable|disable}]  
[filter-unregistered-frames {enable|disable}]  
[priority <0-7>] [name <line>]
```

The `vlan ports` command is in the config command mode.

[Table 84](#) describes the parameters and variables for the `vlan ports` command.

Table 84 vlan ports command parameters and variables

Parameters and variables	Description
<portlist>	Enter the port number(s) you want to configure for a VLAN.
tagging {enable disable}	Enables or disables the port as a tagged VLAN member for egressing packet.
pvid <1-4094>	Associates the port with a specific VLAN
filter-tagged-frame {enable disable}	Enables or disables the port to filter received tagged packets.
filter-untagged-frame {enable disable}	Enables or disables the port to filter received untagged packets.
filter-unregistered-frames {enable disable}	Enables or disables the port to filter received unregistered packets.

Table 84 vlan ports command parameters and variables (continued)

Parameters and variables	Description
priority <0-7>	Sets the port as a priority for the switch to consider as it forwards received packets.
name <line>	Enter the name you want for this port. Note: This option can only be used if a single port is specified in the <portlist>.

vlan members command

The `vlan members` command adds a port to or deletes a port from a VLAN. The syntax for the `vlan members` command is:

```
vlan members [add|remove] <1-4094> <portlist>
```

The `vlan members` command is in the config mode.

[Table 85](#) describes the parameters and variables for the `vlan members` command.

Table 85 vlan members command parameters and variables

Parameters and variables	Description
add remove	Adds a port to or removes a port from a VLAN. Note: If you omit this parameter, you are setting the exact port membership for the VLAN; the prior port membership of the VLAN is discarded and replaced by the new list of ports.
<1-4094>	Specifies the target VLAN.
portlist	Enter the list of port(s) you are adding, removing, or assigning to the VLAN.

show vlan mac-address command

The `show vlan mac-address` command displays the configured MAC address for a MAC source address-based VLAN. The syntax for the `show vlan mac-address` command is:

```
show vlan mac-address <1-4094> [address H.H.H]
```

The `show vlan mac-address` command is in the `privExec` mode.

[Table 86](#) describes the parameters and variables for the `show vlan mac-address` command.

Table 86 show vlan mac-address command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to display MAC source addresses for.
address H.H.H	Specifies a particular MAC address to display; enter the MAC address in the H.H.H. format. Note: If you omit this parameter, the system displays the entire table.

[Figure 30](#) displays sample output from the `show vlan mac-address` command.

Figure 30 show vlan mac-address command output

```
BPS2000(config)#show vlan mac-address 6
Active MAC Addresses
-----
08-00-01-02-02-03
```

vlan mac-address command

The `vlan mac-address` command adds MAC addresses to MAC source-address-based VLANs. The `vlan mac-address` syntax is:

```
vlan mac-address <1-4094> address <H.H.H>
```

The `vlan mac-address` command is in the config command mode.

[Table 87](#) describes the parameters and variables for the `vlan mac-address` command.

Table 87 vlan mac-address command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to add a MAC source address to.
address <H.H.H>	Enter the MAC source address to assign to the VLAN.

no vlan mac-address command

The `no vlan mac-address` command removes MAC addresses from MAC source-address-based VLANs. The `no vlan mac-address` syntax is:

```
no vlan mac-address <1-4094> address <H.H.H>
```

The `no vlan mac-address` command is in the config command mode.

[Table 87](#) describes the parameters and variables for the `no vlan mac-address` command.

Table 88 no vlan mac-address command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the number of the VLAN you want to remove a MAC source address from.
address <H.H.H.>	Enter the MAC source address to remove from the VLAN.

Displaying multicast membership

You can display the membership of multicast groups using the CLI.

show vlan multicast membership command

The `show vlan multicast membership` command displays the IP multicast sessions in the network. The syntax for the `show vlan multicast membership` command is:

```
show vlan multicast membership <1-4094>
```

The `show vlan multicast membership` command is in the `privExec` mode.

[Table 89](#) describes the parameters and variables for the `show vlan multicast membership` command.

Table 89 show vlan multicast membership command parameters and variables

Parameters and variables	Description
<1-4094>	Specifies the VLAN to display IP multicast sessions.

[Figure 31](#) displays sample output from the `show vlan multicast membership` command.

Figure 31 show vlan multicast membership command output

```
BPS2000#show multicast membership 1
Multicast Group Address Unit Port
-----
2239.255.118.187      1    19
2239.255.118.187      2    17
2239.255.118.187      2    19
2239.255.29.77        2    17
2239.255.29.77        2    19
2239.255.118.187      3    17
2239.255.118.187      3    18
2239.255.29.77        3    17
```

Using IGMP snooping

You can configure and display IGMP snooping parameters using the CLI. This section covers:

- [“show vlan igmp command,”](#) next
- [“vlan igmp command”](#) on page 154
- [“default vlan igmp command”](#) on page 155

show vlan igmp command

The `show vlan igmp` command displays the IGMP snooping configuration. The syntax for the `show vlan igmp` command is:

```
show vlan igmp <1-4094>
```

The `show vlan igmp` command is in the `privExec` mode.

[Table 90](#) describes the parameters and variables for the `show vlan igmp` command.

Table 90 show igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Specifies the VLAN to display IGMP snooping configuration.

[Figure 32](#) displays sample output from the `show vlan igmp` command.

Figure 32 show vlan igmp command output

```
BPS2000#show vlan igmp 1
Snooping: Enabled
Proxy: Enabled
Robust Value: 2
Query Time: 125 seconds
IGMPv1 Static Router Ports:
IGMPv2 Static Router Ports:
```

vlan igmp command

The `vlan igmp` command configures IGMP snooping parameters. The syntax for the `vlan igmp` command is:

```
vlan igmp <1-4094> [snooping {enable|disable}]
[proxy {enable|disable}] [robust-value <value>]
[query-interval <time>] [v1-members <portlist>] [v2-members
<portlist>]
```

The `vlan igmp` command is in the config mode.

[Table 91](#) describes the parameters and variables for the `vlan igmp` command.

Table 91 vlan igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the VLAN to configure for IGMP.
snooping {enable disable}	Enables or disables the VLAN for IGMP snooping.
proxy {enable disable}	Enables or disables the VLAN for IGMP proxy.
robust-value <value>	Enter the robust value you want for IGMP.
query-interval <time>	Enter the number of seconds you want for the query interval of IGMP.
v1-members <portlist>	Enter the list of ports for port membership for IGMP v1.
v2-members <portlist>	Enter the list of ports for port membership for IGMP v2.

default vlan igmp command

The `default vlan igmp` command sets all IGMP snooping parameters to the factory default settings. The syntax for the `default vlan igmp` command is:

```
default vlan igmp <1-4094>
```

The `default vlan igmp` command is in the config mode.

[Table 91](#) describes the parameters and variables for the `default vlan igmp` command.

Table 92 default vlan igmp command parameters and variables

Parameters and variables	Description
<1-4094>	Enter the VLAN to default IGMP settings to factory default.

Chapter 6

Policy-enabled networks and QoS

This chapter describes how to configure DiffServ and Quality of Service (QoS) parameters for policy-enabled networks. This chapter covers the following topics:

- “Displaying QoS parameters,” next
- “Resetting” on page 168
- “Configuring COPS” on page 168
- “Configuring QoS interface groups” on page 169
- “Configuring DSCP and 802.1p and queue associations” on page 172
- “Configuring QoS filters and filter groups” on page 174
- “Configuring QoS actions” on page 180
- “Configuring QoS meters” on page 181
- “Gathering QoS statistics” on page 183
- “Configuring QoS policies” on page 184
- “Reordering packets” on page 186

Refer to the *Using the Business Policy Switch 2000 Software Version 1.2* for more information on policy-enable networks, Differentiated Services, and QoS. Refer to *Using Web-based Management for the Business Policy Switch 2000 Software Version 1.2* for information on configuring these features using the Web-based management system, and refer to *Reference for the Business Policy Switch 2000 Management Software Version 1.2* for configuration information for the DM.



Note: When you use the `ignore` value in QoS, the system matches all values for that parameter.

Displaying QoS parameters

You can display QoS parameters using the CLI.

show qos command

The `show qos` command displays the current QoS policy configuration. The syntax for the `show qos` command is:

```
show qos [interface-groups|interface-assignments|
egressmap|ingressmap|ip-filters|ip-filter-sets|l2-filters|
l2-filter-sets|actions|meters|policies|queue-sets|
queue-set-assignments|agent|statistics]
```

The `show qos` command is in the `privExec` command mode.

[Table 93](#) describes the parameters and variables for the `show qos` command.

Table 93 show qos command parameters and variables

Parameters and variables	Description
interface-groups	Displays configured interface groups.
interface-assignments	Displays interface-to-interface group assignments.
egressmap	Displays DSCP-to-802.1p priority and loss-sensitivity mapping.
ingressmap	Displays 802.1p priority-to-DSCP mapping.
ip-filters	Displays defined IP filters.
ip-filter-sets	Displays defined IP filter sets.
l2-filters	Displays defined Layer 2 filters.
l2-filter-sets	Displays defined Layer 2 filter sets.
actions	Displays defined QoS action entries.
meters	Displays defined traffic metering entries.
policies	Displays configured QoS policies.
queue-sets	Displays current queue set information.
queue-set-assignments	Displays 802.1p priority-to-queue assignments by queue set.
agent	Displays QoS agent configuration parameters.
statistics	Displays QoS policy statistics.

Figure 33 displays sample output from the `show qos interface-groups` command.

Figure 33 show qos interface-groups command output

```
BPS2000#show qos interface-groups
```

Role Combination	Interface Class	Capabilities	Storage Type
allBPSIfcs	Untrusted	Input 802, Input IP	Read Only

Figure 34 displays sample output from the `show qos interface-assignments` command.

Figure 34 show qos interface-assignments command output

```
BPS2000#show qos interface-assignments
IfIndex Role Combination
-----
1         allBPSIfcs
2         allBPSIfcs
3         allBPSIfcs
4         allBPSIfcs
5         allBPSIfcs
6         allBPSIfcs
7         allBPSIfcs
8         allBPSIfcs
9         allBPSIfcs
10        allBPSIfcs
11        allBPSIfcs
12        allBPSIfcs
13        allBPSIfcs
14        allBPSIfcs
15        allBPSIfcs
16        allBPSIfcs
17        allBPSIfcs
18        allBPSIfcs
19        allBPSIfcs
20        allBPSIfcs
38        allBPSIfcs
```

[Figure 35](#) displays sample output from the show qos egressmap command.

Figure 35 show qos egressmap command output

DSCP	802.1p	Priority	Drop	Precedence
0	0		Not	Loss Sensitive
1	0		Not	Loss Sensitive
2	0		Not	Loss Sensitive
3	0		Not	Loss Sensitive
4	0		Not	Loss Sensitive
5	0		Not	Loss Sensitive
6	0		Not	Loss Sensitive
7	0		Not	Loss Sensitive
8	2		Not	Loss Sensitive
9	0		Not	Loss Sensitive
10	2		Loss	Sensitive
11	0		Not	Loss Sensitive
12	2		Not	Loss Sensitive
13	0		Not	Loss Sensitive
14	2		Not	Loss Sensitive
15	0		Not	Loss Sensitive
16	3		Not	Loss Sensitive
17	0		Not	Loss Sensitive
18	3		Loss	Sensitive
19	0		Not	Loss Sensitive

Figure 36 displays sample output from the show qos ingressmap command.

Figure 36 show qos ingressmap command output

```
BPS2000#show qos ingressmap
802.1p Priority DSCP
```

0	0
1	0
2	10
3	18
4	26
5	34
6	46
7	48

Figure 37 displays sample output from the show qos ip-filters command.

Figure 37 show qos ip-filters command output

```
BPS2000#show qos ip-filters
```

Id	Destination	Source	DSCP	Protocol	Dest		Src	
	Addr / Mask	Addr / Mask			L4 Port		L4 Port	
1	Ignore	Ignore	Ignore	Ignore	0		0	
	Ignore	Ignore						
2	10.10.1.102	Ignore	Ignore	Ignore	0		0	
	255.255.255.255	Ignore						

Figure 38 displays sample output from the show qos ip-filter-sets command.

Figure 38 show qos ip-filter-sets command output

```
BPS2000#show qos ip-filter-sets
IP Filter Sets
```

<u>Id</u>	<u>Name</u>	<u>Acl Id</u>	<u>Ace Id</u>	<u>Ace Order</u>
2	G1-ip	1	2	2

Figure 39 displays sample output from the show qos l2-filters command.

Figure 39 show qos l2-filters command output

```
BPS2000#show qos l2-filters
```

<u>Id</u>	<u>VLAN</u>	<u>VLAN Tag</u>	<u>Ether Type</u>	<u>802.1p Priority</u>	<u>DSCP</u>	<u>Protocol</u>	<u>Dest IP L4 Port</u>		<u>Src IP L4 Port</u>	
							<u>Min</u>	<u>Max</u>	<u>Min</u>	<u>Max</u>
1	Ignore	Ignore	Ignore		Ignore	Ignore	Ignore	Ignore	Ignore	Ignore
2	Ignore	Ignore	0x800	Ignore	63	Ignore	Ignore	Ignore	Ignore	Ignore
3	Ignore	Ignore	Ignore		Ignore	Ignore	Ignore	Ignore	Ignore	Ignore
4	Ignore	Ignore	Ignore	0,1,2,3,	Ignore	Ignore	Ignore	Ignore	Ignore	Ignore
5	Ignore	Ignore	0x800		1	Ignore	Ignore	Ignore	Ignore	Ignore

```
BPS2000#
```

Figure 40 displays sample output from the show qos l2-filter-sets command.

Figure 40 show qos l2-filter-sets command output

```
BPS2000#show qos l2-filter-sets
Layer2 Filter Sets
```

<u>Id</u>	<u>Name</u>	<u>Acl Id</u>	<u>Ace Id</u>	<u>Ace Order</u>
1	fGrp1	1	1	1
2	fGrp2	2	1	1

Figure 41 displays sample output from the show qos actions command.

Figure 41 show qos actions command output

```
BPS2000#show qos actions
```

<u>Id</u>	<u>Name</u>	<u>Drop</u>	<u>Update DSCP</u>	<u>Set Drop Precedence</u>	<u>802.1p Priority</u>
1	TX1	False	-1	Use Egress Map	Use Egress Map
2	Drop1	True	24	Use Defaults	Use Defaults
3	TX-U	False	38	Use Defaults	Use Defaults
4	Drop-U	True	36	Use Defaults	Use Defaults
5	act5	False	-1	Ignore	Ignore

Figure 42 displays sample output from the show qos meters command.

Figure 42 show qos meters command output

```
BPS2000#show qos meters
```

Id	Name	Data	Commit	Commit	In-Profile Action	Out-Profile Action
		Spec (Kbps)	Rate (Bytes)	Burst		
1	M1	Metered	100	2047	TX1	Drop1
2	M2-Unt	Metered	10	2047	TX-U	Drop-U

Figure 43 displays sample output from the show qos policies command.

Figure 43 show qos policies command output

```
BPS2000#show qos policies
```

Id	Name	Filter	Set	Fltr	Role	Order	Meter
				Type			
1	tgt1	G1-ip	IP	allBPSIfcs	1	M2-Unt	

Figure 44 displays sample output from the show qos queue-sets command.

Figure 44 show qos queue-sets command output

```

BPS2000#show qos queue-sets
Set Queue  General      Extended  Bandwidth  Absolute  Bandwith  Service  Size
ID  ID    Discipline Discipline    (%)    Bandwidth Allocation  Order  (Bytes)
                                     (Kbps)
-----
1   1     Priority    0.0         100      0         Relative   1      64000
1   2     Weight Fair 0.0         50        0         Relative   2      48000
1   3     Weight Fair 0.0         30        0         Relative   2      40000
1   4     Weight Fair 0.0         20        0         Relative   2      32000
2   1     Priority    0.0         100      0         Relative   1      38400
2   2     Priority    0.0         100      0         Relative   2     153600

```

Figure 45 displays sample output from the show qos queue-set-assignments command.

Figure 45 show qos queue-set-assignments command output

```
BPS2000#show qos queue-set-assignment
Queue Set 1

802.1p Priority Queue
-----
0                4
1                4
2                3
3                3
4                2
5                2
6                1
7                1
Queue Set 2

802.1p Priority Queue
-----
0                2
1                2
2                2
3                2
4                2
5                2
6                1
7                1
```

[Figure 46](#) displays sample output from the show qos agent command.

Figure 46 show qos agent command output

```
BPS2000#show qos agent
QoS Policy Server Control: Enabled
QoS Policy Agent Retry Timer: 5 seconds
Allow Packet Reordering: Enabled
Maintain Policing Statistics: Enabled
```

Figure 47 displays sample output from the `show qos statistics` command.

Figure 47 `show qos statistics` command output

```
BPS2000#show qos statistics
```

Id	Name	Packet Hits	Overflow Packet Hits	Total Octets	Total Overflow Octets
----	------	----------------	----------------------------	-----------------	-----------------------------

1	tgt1	0	0	0	0
---	------	---	---	---	---

Id	Name	InProfile Octets	InProfile Overflow Octets	OutProfile Octets	OutProfile Overflow Octets
----	------	---------------------	---------------------------------	----------------------	----------------------------------

1	tgt1	0	0	0	0
---	------	---	---	---	---

Resetting

You can reset the system to the factory defaults.

qosagent reset-default command

The `qosagent reset-default` command deletes all installed states and resets the system to factory default values. The syntax for the `qosagent reset-default` command is:

```
qosagent reset-default
```

The `qosagent reset-default` command is in the config mode.

The `qosagent reset-default` command has no parameters or variables.

Configuring COPS

You can enable COPS-PR, the dynamic management system, using the CLI.

qosagent server-control command

The `qosagent server-control` command enables COPS. The syntax for the `qosagent server-control` command is:

```
qosagent server-control {enable|disable} [retry-timer  
<no-retry|1-86400>]
```

The `qosagent server-control` command is in the config mode.

[Table 94](#) describes the parameters and variables for the `qosagent server-control` command.

Table 94 qosagent server-control command parameters and variables

Parameters and variables	Description
enable disable	Enables COPS.
retry-timer <no-retry 1-86400>	Sets the value for the retry timer: <ul style="list-style-type: none">no retry—connection retry not attempted after a failed attempt1-86400—specifies the seconds between receipt of a connection termination/rejection notification and initiation of a new connection request

Configuring QoS interface groups

You can add or delete ports to or from an interface group or add or delete the interface groups themselves. This section covers:

- “[qos if-assign command](#),” next
- “[qos if-group command](#)” on page 170
- “[qos if-assign-list command](#)” on page 171

qos if-assign command

The `qos if-assign` command adds or deletes ports to or from a defined interface group. The syntax for the `qos if-assign` command is:

```
qos if-assign name <tag> {add|del} [port <portnum>]
```

The `qos if-assign` command is in the `config-if` command mode.

[Table 95](#) describes the parameters and variables for the `qos if-assign` command.

Table 95 qos if-assign command parameters and variables

Parameters and variables	Description
name <tag>	Enter the name of the defined interface group.
add del	Adds or deletes the port to or from the interface group.
port <portnum>	Enter the port(s) the port to add or delete to interface group. Note: If you omit this parameter, the system uses the port number specified when you issued the <code>interface</code> command.

qos if-group command

The `qos if-group` command adds or deletes interface groups. The syntax for the `qos if-group` command is:

```
qos if-group name <tag> {create class <ifclass>|delete}
```

The `qos if-group` command is in the `config` command mode.

[Table 96](#) describes the parameters and variables for the `qos if-group` command.

Table 96 qos if-group command parameters and variables

Parameters and variables	Description
name <tag>	Enter the name of the interface group you are working with; maximum of 32 alphanumeric characters.
create class <ifclass>	Defines a new interface group and specifies the class of traffic received on interfaces associated with this interface group: <ul style="list-style-type: none"> • trusted • untrusted • unrestricted
delete	Deletes an existing interface group.

qos if-assign-list command

The `qos if-assign-list` command adds or deletes a list of ports to or from a defined interface group. The syntax for the `qos if-assign-list` command is:

```
qos if-assign-list name <tag> {add|del} [portlist
<portlist>]
```

The `qos if-assign-list` command is in the config-if command mode.

[Table 95](#) describes the parameters and variables for the `qos if-assign-list` command.

Table 97 qos if-assign-list command parameters and variables

Parameters and variables	Description
name <tag>	Enter the name of the defined interface group.
add del	Adds or deletes the port to or from the interface group.
portlist <portlist>	Enter the list of ports to add or delete to interface group. Note: If you omit this parameter, the system uses the port number specified when you issued the <code>interface</code> command.



Note: You cannot delete interface groups that are referenced by an installed policy or associated with device interfaces.

Configuring DSCP and 802.1p and queue associations

You can configure the DSCP, IEEE 802.1p priority, and queue set association using the CLI. This section covers:

- [“qos egressmap command,”](#) next
- [“qos ingressmap command”](#) on page 173
- [“qos queue-set-assignment command”](#) on page 174

qos egressmap command

The `qos egressmap` command configures DSCP-to-802.1p priority and drop precedence associations that are used for assigning these values at packet egress, based on the DSCP in the received packet. The syntax for the `qos egressmap` command is:

```
qos egressmap ds <dscp> lp <ieee1p> dp <dropprec>
```

The `qos egressmap` command is in the config command mode.

[Table 98](#) describes the parameters and variables for the `qos egressmap` command.

Table 98 qos egressmap command parameters and variables

Parameters and variables	Description
ds <dscp>	Enter the DSCP value used as a lookup key for 802.1p priority and drop precedence at egress when appropriate; range is between 0 and 63.
1p <ieee1p>	Enter the 802.1p priority value associated with the DSCP; range is between 0 and 7.
dp <dropprec>	Enter the drop precedence values associated with the DSCP: <ul style="list-style-type: none"> • loss-sensitive • not-loss-sensitive

qos ingressmap command

The `qos ingressmap` command configures 802.1p priority-to-DSCP associations that are used for assigning default values at packet ingress, based on the 802.1p priority value in the received packet. The syntax for the `qos ingressmap` command is:

```
qos ingressmap 1p <ieee1p> ds <dscp>
```

The `qos ingressmap` command is in the config command mode.

[Table 99](#) describes the parameters and variables for the `qos ingressmap` command.

Table 99 qos ingressmap command parameters and variables

Parameters and variables	Description
1p <ieee1p>	Enter the 802.1p priority value used as a lookup key for DSCP assignment at ingress when appropriate; range is between 0 and 7.
ds <dscp>	Enter the DSCP value associated with the 802.1p priority value; range is between 0 and 63.

qos queue-set-assignment command

The `qos queue-set-assignment` command associates the 802.1p priority values with a specific queue **within** a specific queue set. This association determines the egress scheduling treatment that traffic with a specific 802.1p priority value receives. The syntax for the `qos queue-set-assignment` command is:

```
qos queue-set-assignment queue-set <setid> 1p <ieee1p>
queue <qid>
```

The `qos queue-set-assignment` command is in the config command mode.

[Table 100](#) describes the parameters and variables for the `qos queue-set-assignment` command.

Table 100 qos queue-set-assignment command parameters and variables

Parameters and variables	Description
queue-set <setid>	Enter the queue set ID.
1p <ieee1p>	Enter the 802.1p priority value for which the queue association is being modified; range is between 0 and 7.
queue <qid>	Enter the queue within the identified queue set to assign the 802.1p priority traffic at egress.

Configuring QoS filters and filter groups

You can configure filters and filter sets using the CLI. This section covers:

- [“qos ip-filter command,”](#) next
- [“qos ip-filter-set command”](#) on page 176
- [“qos l2-filter command”](#) on page 177
- [“qos l2-filter-set command”](#) on page 179

qos ip-filter command

The `qos ip-filter` command adds or deletes IP filters. The syntax for the `qos ip-filter` command is:

```
qos ip-filter <fid> {create [src-ip <src-ip-info>] [dst-ip
<dst-ip-info>] [ds-field <dscp>] [protocol <protocoltype>]
[src-port <port>] [dst-port <port>] |delete}
```

The `qos ip-filter` command is in the config command mode.

[Table 101](#) describes the parameters and variables for the `qos ip-filter` command.

Table 101 qos ip-filter command parameters and variables

Parameters and variables	Description
<fid>	Enter an integer to specify the filter ID.
create	Defines a new IP filter with the specified filter ID.
src-ip <src-ip-info>	Enter the source IP address and mask in the form of a.b.c.d/x or a.b.c.d x.x.x.x. Default is 0.0.0.0.
dst-ip <dst-ip-info>	Enter the destination IP address and mask in the form of a.b.c.d/x or a.b.c.d x.x.x.x. Default is 0.0.0.0.
ds-field <dscp>	Enter 6-bit DSCP value; range is 0 to 63. Default is ignore.
protocol <protocoltype>	Enter the protocol type: <ul style="list-style-type: none"> ignore icmp tcp udp Default is ignore.
src-port <port>	Enter TCP/UDP source port value. Default is ignore.
dst-port <port>	Enter TCP/UDP destination port value. Default is ignore.
delete	Deletes the IP filter with the specified filter ID.



Note: If you omit any parameter, the default value is used.
You cannot delete an IP filter that is referenced by an IP filter set.

qos ip-filter-set command

The `qos ip-filter-set` command adds or deletes currently defined IP filters into an IP filter set. The syntax for the `qos ip-filter-set` command is:

```
qos ip-filter-set <fgid> {create set <setid> [name  
<setname>] filter <fid> filter-prec <prec>|delete}
```

The `qos ip-filter-set` command is in the config command mode.

[Table 102](#) describes the parameters and variables for the `qos ip-filter-set` command.

Table 102 qos ip-filter-set command parameters and variables

Parameters and variables	Description
<fgid>	Enter an integer to specify the filter group ID; range is 1 to 65535.
create set <setid>	Initiates creation of an IP filter set with the designated filter set ID. Enter the IP filter set ID; range is 1 to 65535
name <setname>	Assigns a name to the designated filter set ID. Enter the name for the filter set; maximum is 16 alphanumeric characters
filter <fid>	Adds an IP filter to the filter set; range is 1 to 65535.
filter-prec <prec>	Specifies the precedence, or filter evaluation order, within the set. Enter the precedence value you want for this filter; range is 1 to 65535.
delete	Deletes the IP filter set.



Note: You must define the filter before adding it to a filter set.
 You cannot delete an IP filter set that is referenced in an installed policy.
 You cannot delete the last IP filter in an IP filter set that is referenced in an installed policy.

qos l2-filter command

The `qos l2-filter` command adds and deletes Layer 2 (L2) filters. The syntax for the `qos l2-filter` command is:

```
qos l2-filter <fid> {create [ethertype <etype>] [vlan <vid>]
[vlan-tag <vtag>] [priority <ieee1p-seq>] [ds-field <dscp>]
[protocol <protocoltype>] [src-port-min <port> src-port-max
<port>] [dst-port-min <port> dst-port-max <port>] |delete}
```

The `qos l2-filter` command is in the config mode.

[Table 103](#) describes the parameters and variables for the `qos l2-filter` command.

Table 103 qos l2-filter command parameters and variables

Parameters and variables	Description
<fid>	Enter an integer to specify the filter ID; range is 1 to 65535.
create	Defines a new L2 filter with the specified filter ID.
ethertype <etype>	Enter the Ethernet type in the form of 0xXXXX, for example, 0x0801. Default is ignore.
vlan <vid>	Enter the number of the VLAN ID. Default is ignore

Table 103 qos l2-filter command parameters and variables (continued)

Parameters and variables	Description
vlan-tag <vtag>	Enter the type of VLAN tagging filter you want: <ul style="list-style-type: none"> • tagged • untagged • ignore Default is ignore.
priority <ieee1p-seq>	Enter the 802.1p priority values; range from 0 to 7. Enter in the form of [a,(b)*(c-d)*], for example, 0, 3-4, 7. Default is ignore.
ds-field <dscp>	Enter a 6-bit value for the DS field; range is from 0 to 63. Default is ignore.
protocol <protocoltype>	Enter the protocol type: <ul style="list-style-type: none"> • ignore • icmp • tcp • udp Default is ignore.
src-port-min <port>	Enter the TCP/UDP minimum source port value; range is 0 to 65535. Default is 0 = ignore.
src-port-max <port>	Enter the TCP/UDP maximum source port value; range is 0 to 65535. Default is 65535 = ignore.
dst-port-min <port>	Enter the TCP/UDP minimum destination port value; range is 0 to 65535. Default is 0 = ignore.
dst-port-max <port>	Enter the TCP/UDP maximum destination port value; range is 0 to 65535. Default is 65535 = ignore.
delete <fid>	Enter the filter ID you want to delete.



Note: If you omit any parameter, the default value is used. You cannot delete a filter that is referenced by an L2 filter set.

qos l2-filter-set command

The `qos l2-filter-set` command adds and deletes Layer 2 filters into an L2 filter set. The syntax for the `qos l2-filter-set` command is:

```
qos l2-filter-set <fgid> {create set <setid> [name
<setname>] filter <fid> filter-prec <prec>|delete}
```

The `qos l2-filter-set` command is in the config command mode.

[Table 104](#) describes the parameters and variables for the `qos l2-filter-set` command.

Table 104 qos l2-filter-set command parameters and variables

Parameters and variables	Description
<fgid>	Enter an integer to specify the filter group ID you want to work with; range is 1 to 65535.
create set <setid>	Initiates creation of an L2 filter set with the designated filter set ID. Enter the IP filter set ID; range is 1 to 65535.
name <setname>	Assigns a name to the designated filter set ID. Enter the name for the filter set; maximum is 16 alphanumeric characters.
filter <fid>	Adds an L2 filter to the filter set; range is 1 to 65535.
filter-prec <prec>	Specifies the precedence, or filter evaluation order, within the set. Enter the precedence value you want for this filter; range is 1 to 65535.
delete	Deletes the L2 filter set.



Note: You must define the filter before adding it to a filter set. You cannot delete an L2 filter set that is referenced in an installed policy. You cannot delete the last L2 filter in an L2 filter set that is referenced in an installed policy.

Configuring QoS actions

You can configure QoS actions, which directs the BPS 2000 to take specific action on each packet, using the CLI.

qos action command

The `qos action` command creates or deletes a QoS action. The syntax for the `qos action` command is:

```
qos action <actid> [name <actname>] [drop-action  
{enable|disable}] [update-dscp <dscp>] [update-tp  
{<ieeelp>|default|use-egress-map}] [set-drop-prec  
{loss-sensitive|not-loss-sensitive|default|use-egress-map}]
```

The `qos action` command is in the config mode.

[Table 105](#) describes the parameters and variables for the `qos action` command.

Table 105 qos action command parameters and variables

Parameters and variables	Description
<actid>	Enter an integer to specify the QoS action; range is 1 to 65535.
name <actname>	Assigns a name to a QoS action with the designated action ID. Enter the name for the action; maximum is 16 alphanumeric characters
drop-action {enable disable}	Specifies whether packets should be dropped or not; the drop action equals enable. Default is disable.
update-dscp <dscp>	Specifies whether DSCP value should be updated or left unchanged; unchanged equals ignore. Enter the 6-bit DSCP value you want; range is 0 to 63. Default is ignore.

Table 105 qos action command parameters and variables (continued)

Parameters and variables	Description
update-1p	Specifies whether 802.1p priority value should be updated or left unchanged; unchanged equals ignore: <ul style="list-style-type: none"> • ieee1p—enter the value you want; range is 0 to 7 • default—allows the value to be derived based on assignment of other action parameters • use-egress-map—uses the egress map to assign value Default is default.
set-drop-prec {loss-sensitive not-loss-sensitive default use-egress-map}	Enter the loss-sensitivity value you want: <ul style="list-style-type: none"> • loss-sensitive • not-loss-sensitive • default • use-egress-map Default is use default.



Note: Certain options may be restricted based on the meter/policy associated with the specific action.

You cannot delete an action that is referenced in an installed policy or meter.

Configuring QoS meters

Using the CLI, you set meters. You *must* set a meter when configuring QoS. You can set a meter for either metered data or for nonmetered data.

If you want to meter, or police, the traffic, configure the committed rate, burst rate, burst duration, in-profile action, and out-of-profile action.

For nonmetered data, configure only in-profile action.

qos meter command

The `qos meter` command creates or deletes a QoS meter. The syntax for the `qos meter` command is:

```
qos meter <metid> {create [name <metname>] metering-reqd
{enable committed-rate <rate> max-burst-rate <burstrate>
[max-burst-duration <burstdur>] {in-profile-action
<actid>|in-profile-action-name <actname>}}
{out-profile-action <actid>|out-profile-action-name
<actname>}}|disable {in-profile-action
<actid>|in-profile-action-name <actname>}}|delete}
```

The `qos meter` command is in the `config` command mode.

[Table 106](#) describes the parameters and variables for the `qos meter` command.

Table 106 qos meter command parameters and variables

Parameters and variables	Description
<metid>	Enter an integer to specify the QoS meter; range is 1 to 65535.
name <metname>	Assigns a name to the QoS meter with the designated meter ID. Enter name for meter; maximum is 16 alphanumeric characters.
metering-reqd	Enables metering data. Default is disable.
enable committed-rate <rate>	Enables specifying the rate that traffic must not exceed for extended periods to be considered in-profile. Enter the rate in Kb/s for in-profile traffic; range is 1 to 65535 Kb/s.
max-burst-rate <burstrate>	Specifies the largest burst of traffic that can be received a given time for the traffic to be considered in-profile. Used in calculating the committed burst size. Enter the burst size in Kb/s for in-profile traffic; range is 1 to 65535 Kb/s
max-burst-duration <burstdur>	Specifies the amount of time that the largest burst of traffic that can be received for the traffic to be considered in-profile. Used in calculating the committed burst size. Enter the burst duration in ms for in-profile traffic; range is 1 to 65535 ms.
in-profile-action <actid>	Enter the action ID for in-profile traffic; range is 1 to 65535.
in-profile-action-name <actname>	Enter the action name for in-profile traffic; maximum is 16 alphanumeric characters.

Table 106 qos meter command parameters and variables (continued)

Parameters and variables	Description
out-profile-action <actid>	Enter the action ID for out-of-profile traffic; range is 1 to 65535.
out-profile-action-name <actname>	Enter the action name for in-profile traffic; maximum is 16 alphanumeric characters.
disable	Disables metering traffic. Note: You must still configure an ID or a name for in-profile actions.
in-profile-action <actid>	Enter the action ID for in-profile traffic; range is 1 to 65535.
in-profile-action-name <actname>	Enter the action name for in-profile traffic; maximum is 16 alphanumeric characters.
delete	Deletes the specified meter.



You must define an action before referencing that action with a meter.
You cannot delete a meter that is referenced in an installed policy.

Gathering QoS statistics

You can gather statistics on QoS, such as the number of in-profile octets and out-of-profile octets. These statistics can serve as an important method to evaluate the effectiveness of the installed policies. However, tracking these statistics requires additional system resources, which limits the number of filters for classification.

qosagent police-statistics command

The `qosagent police-statistics` command gathers traffic policing, or metering, statistics. The syntax for the `qosagent police-statistics` command is:

```
qosagent police-statistics {enable|disable}
```

The `qosagent police-statistics` command is in the `config` command mode.

[Table 107](#) describes the parameters and variables for the `qosagent police-statistics` command.

Table 107 `qosagent police-statistics` command parameters and variables

Parameters and variables	Description
enable disable	Set policing statistics to: <ul style="list-style-type: none">• Enable—statistics are tracked by default for all policies defined after this command is issued• Disable—disables tracking statistics for policies defined after this command is issued

Configuring QoS policies

You configure QoS policies using the CLI.

`qos policy` command

The `qos policy` command creates or deletes a QoS policy. The syntax for the `qos policy` command is:

```
qos policy <polid> {create [name <polname>]
if-group <ifgroup> filter-set-type {ip|l2}
{filter-set <setid>|filter-set-name <setname>}
{meter <metid>|meter-name<metname>}}
[track-statistics {enable|disable}]order <order>|
delete}
```

The `qos policy` command is in the `config` command mode.

[Table 108](#) describes the parameters and variables for the `qos policy` command.

Table 108 qos policy command parameters and variables

Parameters and variables	Description
<polid>	Enter an integer to specify the QoS policy; range is 1 to 65535.
create	Creates the QoS policy.
name <polname>	Assigns a name to the QoS policy with the designated policy ID. Enter the name for the policy; maximum is 16 alphanumeric characters.
if-group <ifgroup>	Enter the interface group name to which this policy applies.
filter-set-type {ip l2}	Enter the type of filter set associated with this policy: <ul style="list-style-type: none"> ip—specifies IP filter set l2—specifies Layer 2 filter set
filter-set <setid>	Enter the filter set ID associated with this policy; range is 1 to 65535.
filter-set-name <setname>	Enter the name of the filter set associated with this policy.
meter <metid>	Enter meter ID associated with this policy range is 1 to 65535. Indirectly specifies, through the meter, the action or actions associated with this policy.
meter-name <metname>	Enter the meter name associated with this policy; maximum of 16 alphanumeric characters. Indirectly specifies, through the meter, the action or actions associated with this policy.
track-statistics {enable disable}	Enables maintaining policing statistics on the specified flow. Default is based on value of setting of <code>qosagent police-statistics</code> command.
order <order>	Specifies the evaluation order of this policy in relation to other policies associated with the same interface group. Enter order number; range is 1 to 65535. Note: Policies with a lower order value are evaluated before policies with a higher order number. Evaluation goes from lowest value to highest.
delete	Deletes the specified QoS policy.



You must define all components associated with a policy, including the interface group, filter set, and meter, before referencing those components with a policy.

Reordering packets

Support for certain per-hop behaviors (PHBs) requires packets within a flow be reordered upon transmission. Using the CLI, you can assign packets to specified egress queues.

qosagent packet-reordering command

The `qosagent packet-reordering` command allows you to reorder packets for transmission. The syntax for the `qosagent packet-reordering` command is:

```
qosagent packet-reordering {enable|disable}
```

The `qosagent packet-reordering` command is in the config command mode.

[Table 108](#) describes the parameters and variables for the `qosagent packet-reordering` command.

Table 109 qosagent packet-reordering command parameters and variables

Parameters and variables	Description
enable disable	Set packet-reordering to: <ul style="list-style-type: none">• Enable—allows full flexibility in terms of the egress queue to which a packet is assigned.• Disable—the system verifies that in-profile and out-of-profile actions associated with a flow will not cause packets from the same flow to be assigned to different egress queues.

Appendix A

Command List

This appendix provides the complete CLI command list in alphabetical order, with approximate page references for the beginning pages of further explanations.



Note: This information is presented for reference only and should not be considered to be an exact representation.

Table 110 CLI Command List

Command	Page No.
auto-pvid	page 147
autotopology	page 92
boot [default] [unit <unitno>]	page 70
clear logging [nv]	page 84
clear-stats [port<port num>]	page 87
cli-password {switch stack} {ro rw} <WORD> <WORD> cli-password {switch stack} {serial telnet} {none local radius}	page 36
configure {terminal network memory}	page 42
configure network [load-on-boot {disable use-bootp use-config}] configure network [filename <WORD>] configure network [address <XXX.XXX.XXX.XXX>]	page 57
copy config tftp [address <XXX.XXX.XXX.XXX>] filename <WORD>	page 73
copy tftp config [address <XXX.XXX.XXX.XXX>] filename <WORD>	page 74
default autotopology	page 93
default duplex [port <portnum all>]	page 91
default flowcontrol [port <portnum all>]	page 95
default ip bootp server	page 71
default mac-address-table aging-time	page 49

Table 110 CLI Command List (continued)

Command	Page No.
default rate-limit [port <portnum> all>]	page 99
default set logging	page 84
default snmp trap link-status [port <portnum> all>]	page 81
default spanning-tree [stp <1-8>] [forward-time] [hello-time] [max-age] [priority] [tagged-bpdu]	page 127
default spanning-tree [port <portnum>] [stp <1-8>] [learning] [cost] [priority]	page 130
default speed [port <portnum>]	page 90
default telnet-access	page 68
default terminal {speed length width}	page 54
default vlan igmp <1-4094>	page 155
disable	page 43
download [address <ip>] {image <image-name> [bs450-image <image-name>] diag <filename>}	page 75
duplex [port <portnum> all>] {full half auto}	page 90
eapol [{enable disable}] [port <portnum>] [init] [status authorized unauthorized auto] [traffic-control in-out in] [re-authentication enable disable] [re-authentication-interval <num>] [re-authenticate] [quiet-interval <num>] [transmit-interval <num>] [supplicant-timeout <num>] [server-timeout <num>] [max-request <num>]	page 113
enable	page 41
end	page 43
exit	page 43
flowcontrol [port <portnum>] {asymmetric symmetrid auto disable}	page 94
help	page 40
interface FastEthernet {<portnum> all}	page 42
ip address[stack switch] <XXX.XXX.XXX.XXX> [netmask <XXX.XXX.XXX.XXX>]	page 60
ip bootp server {last needed disable always}	page 70
ip default-gateway <XXX.XXX.XXX.XXX>	page 61
ipmgr list {telnet snmp http}	page 104
ipmgr list {source-ip <1-10> <XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]}	page 105
logout	page 41
mac-address-table aging-time <time>	page 48

Table 110 CLI Command List (continued)

Command	Page No.
mac-security [disable enable] [filtering {enable disable}] [intrusion-detect{enable disable forever}] [intrusion-timer <1-65535>] [learning-ports <portlist>] [learning {enable disable}] [snmp-lock {enable disable}] [snmp-trap {enable disable}]	page 107
mac-security [port <portnum>] {disable enable learning}	page 111
mac-security mac-address-table address <H.H.H.> {port <portnum> security-list <1-32>}	page 108
mac-security security-list <1-32> mac-security security-list <portlist>	page 109
mlt <id> [name <trunkname>] [enable disable] [member <portlist>]	page 133
no auto-pvid	page 147
no autotopology	page 93
no flowcontrol [port <portnum>]	page 94
no ip address {stack switch}	page 61
no ip bootp server	page 71
no ip default-gateway	page 62
no ipmgr {telnet snmp http}	page 104
no ipmgr {source IP [<1-10>]}	page 105
no mac-security	page 110
no mac-security mac-address-table {address <H.H.H> port <portlist> security-list <1-32>}	page 110
no mac-security security-list <1-32>	page 111
no mlt [<id>]	page 134
no port-mirroring	page 137
no radius-server	page 117
no rate-limit [port <portnum>]	page 98
no set logging	page 84
no shutdown [port <portnum>]	page 88
no snmp server [authentication-trap community [ro rw] contact host [<host-ip> <community-string>] [location name]	page 79
no snmp trap link-status [port <portnum> all>]	page 80
no spanning-tree [port <portnum>] [stp <1-8>]	page 131
no telnet-access [source-ip [<1-10>]]	page 67
no tftp-server	page 73

Table 110 CLI Command List (continued)

Command	Page No.
no vlan <1-4094>	page 146
no vlan mac-address <1-4094> address <H.H.H.>	page 151
no web-server	page 69
ping <XXX.XXX.XXX.XXX>	page 56
port-mirroring mode disable	page 135
port-mirroring mode Xrx monitor-port <portnum> mirror-port X <portnum>	
port-mirroring mode XrxOrXtx monitor-port <portnum> mirror-port X <portnum>	
mirror-port-Y <portnum>	
port-mirroring mode XrxOrYtx monitor-port <portnum> mirror-port X <portnum>	
mirror-port-Y <portnum>	
port-mirroring mode XrxYtx monitor-port <portnum> mirror-port X <portnum>	
mirror-port-Y <portnum>	
port-mirroring mode XrxYtxOrYrxXtx monitor-port <portnum> mirror-port X <portnum>	
mirror-port-Y <portnum>	
port-mirroring mode Asrc monitor-port <portnum> mirror-MAC-A <macaddr>	
port-mirroring mode Adst monitor-port <portnum> mirror-MAC-A <macaddr>	
port-mirroring mode AsrcOrAdst monitor-port <portnum> mirror-MAC-A <macaddr>	
port-mirroring mode AsrcBdst monitor-port <portnum> mirror-MAC-A <macaddr>	
mirror-MAC-B <macaddr>	
port-mirroring mode AsrcBdstOrBsrcAdst monitor-port <portnum> mirror-MAC-A <macaddr>	
mirror-MAC-B <macaddr>	
qos action <actid> name <actname>	page 180
qos action <actid> drop-action {enable disable}	
qos action <actid> update-dscsp <dscsp>	
qos action <actid> update-1p {<ieee1p> default use-egress-map}	
qos action <actid> set-drop-prec {loss-sensitive not-loss-sensitive default use-egress-map}	
qos egress map ds <dscsp> 1p <ieee1p> dp <dropprec>	page 172
qos if-assign name <tag> {add del} [port <portnum>]	page 170
qos if-assign-list name <tag> {add del} [portlist <portlist>]	page 171
qos if-group name <tag> {create <ifclass> delete}	page 170
qos ingress map 1p <ieee1p> ds <dscsp>	page 173
qos ip-filter <fid> {create src-ip <src-ip-info>}	page 175
qos ip-filter <fid> {create dst-ip <dst-ip-info>}	
qos ip-filter <fid> {create ds-field <dscsp>}	
qos ip-filter <fid> {create protocol <protocoltype>}	
qos ip-filter <fid> {create src-port <port>}	
qos ip-filter <fid> {create dst-port <port>}	
qos ip-filter <fid> {delete}	

Table 110 CLI Command List (continued)

Command	Page No.
qos ip-filter-set <fgid> {create set <setid> [name <setname>] filter-id <fid> filter-prec <prec>} qos ip-filter-set <fgid> {delete}	page 176
qos l2-filter <fid> {create ethertype <etype>} qos l2-filter <fid> {create vlan <vid>} qos l2-filter <fid> {create vlantag <vtag>} qos l2-filter <fid> {create priority<ieee1p-seq>} qos l2-filter <fid> {create dsfield <dscp>} qos l2-filter <fid> {create protocol <protocoltype>} qos l2-filter <fid> {create src-port <min> src-port <max>} qos l2-filter <fid> {create dst-port <min> dst-port <max>} qos l2-filter <fid> {delete}	page 177
qos l2-filter-set <fgid> {create set <setid> [name <setname>] filter-id <fid> filter-prec <prec>} qos l2-filter-set <fgid> {delete}	page 179
qos meter <metid> {create [name <metname>] metering-reqd {enable committed-rate <rate> max-burst-rate <rate> [max-burst-duration <burstdur>] {in-profile-action <actid> in-profile-action-name {actname} {out-profile-action <actid> out-profile-action-name <actname>}} disable {in-profile-action <actid> in-profile-action-name <actname>}}} qos meter <metid> {delete}	page 182
qos policy <polid> {create [name <polname>] if-group <ifgroup> filter-set-type {ip l2} {filter-set <setid> filter-set-name <setname>} {meter <metid> meter-name <metname>} [track-statistics {enable disable} order <order>]} qos policy <polid> {delete}	page 184
qos queue-set-assignment queue-set <setid> 1p <ieee1p> queue <qid>	page 174
qosagent packet-reordering {enable disable}	page 186
qosagent police-statistics {enable disable}	page 183
qosagent reset-default	page 168
qosagent server-control {enable disable} [retry-timer <no-retry 1-86400>]	page 169
radius-server host <address> [secondary-host <address>] port <num> key <string>	page 116
rate-limit [port <portnum>] {multicast <pct> broadcast <pct> both <pct>}	page 97
renumber unit	page 46
set logging [enable disable] [level critical serious informational] [nv-level critical serious informational none]	page 83
show config-network	page 59
show eapol	page 112
show interfaces	page 76
show ip [bootp] [default-gateway] [address [stack switch]]	page 63

Table 110 CLI Command List (continued)

Command	Page No.
show ipmgr	page 102
show logging [critical] show logging [serious] show logging [informational]	page 82
show mac-address-table [aging-time] show mac-address-table [vid <1-4094>] [address <H.H.H.>]	page 47
show mac-security {config mac-address-table [addr <macaddr>] port security-lists}	page 106
show mlt [utilization <1-6>]	page 132
show port-mirroring	page 135
show port-statistics [port <portnum>]	page 85
show qos interface-groups show qos egressmap show qos ingressmap show qos ip-filter-sets show qos l2-filters show qos l2-filter-sets show qos actions show qos meters show qos policies show qos queue-set-assignments show qos agent show qos statistics	page 158
show radius-server	page 115
show rate-limit	page 96
show spanning-tree {stp <1-8>} {config port}	page 120
show-stack-info	page 45
show stack-oper-mode	page 50
show sys-info	page 44
show telnet-access	page 65
show terminal	page 54
show tftp-server	page 72
show vlan igmp <1-4094>	page 153
show vlan interface info [<portlist>]	page 141
show vlan interface vids [<portlist>]	page 142
show vlan mac-address <1-4094> [<H.H.H.>]	page 150

Table 110 CLI Command List (continued)

Command	Page No.
show vlan multicast membership <1-4094>	page 150
shutdown [port <portnum>]	page 87
snmp trap link-status [port <portnum>]	page 80
snmp-server {{enable disable} authentication-trap community <community-string> [ro rw] contact <text> host <host-ip> <community-string> location >text> name <text>}	page 78
spanning-tree [stp <1-8>] add-vlan <1-4094>	page 127
spanning-tree [stp <1-8>] [forward-time <4-30>] [hello-time <1-10>] [max-age <6-40>] [priority <0-65535>] [tagged-bpdu {enable disable}]	page 126
spanning-tree [port <portnum>] [stp <1-8>] [learning {disable normal fast}] [cost <1-65535>] [priority <0-255>]	page 129
spanning-tree [stp <1-8>] remove-vlan <1-4094>	page 128
spanning-tree stp <2-8> create	page 123
spanning-tree stp <2-8> delete	page 124
spanning-tree stp <2-8> disable	page 125
spanning-tree stp <2-8> enable	page 124
speed [port <portnum all>] {10 100 1000 auto}	page 89
stack oper-mode {bps2000 hybrid}	page 50
telnet-access [enable disable] [login-timeout <1-10>] [retry <1-100>] [inactive-timeout <0-60>] [logging {none access failures all}] [source-ip <1-10> <XXX.XXX.XXX.XXX> [mask <XXX.XXX.XXX.XXX>]]	page 66
terminal {2400 4800 9600 19200 38400} length <1-132> width <1-132>	page 55
tftp-server <XXX.XXX.XXX.XXX>	page 73

Table 110 CLI Command List (continued)

Command	Page No.
vlan create <1-4094> name <line>	page 143
vlan create <1-4094> learning IVL	
vlan create <1-4094> learning SVL	
vlan create <1-4094> type macsa	
vlan create <1-4094> type port	
vlan create <1-4094> type protocol-ApltkEther2Snap	
vlan create <1-4094> type protocol-decEther2	
vlan create <1-4094> type protocol-decOtherEther2	
vlan create <1-4094> type protocol-ipEther2	
vlan create <1-4094> type protocol-ipv6Ether2	
vlan create <1-4094> type protocol-ixp802.2	
vlan create <1-4094> type protocol-ixp802.3	
vlan create <1-4094> type protocol-ixpEther2	
vlan create <1-4094> type protocol-ixpSnap	
vlan create <1-4094> type protocol-Netbios	
vlan create <1-4094> type protocol-RarpEther2	
vlan create <1-4094> type protocol-sna802.2	
vlan create <1-4094> type protocol-snaEther2	
vlan create <1-4094> type protocol-userdef	
vlan create <1-4094> type protocol-vinesEther2	
vlan create <1-4094> type protocol-xnsEther2	
vlan delete <1-4094>	page 146
vlan igmp <1-4094> [snooping {enable disable}] [proxy {enable disable}] [robust-value <value>] [query-interval <time>] [v1-members <portlist>] [v2-members <portlist>]	page 154
vlan mac-address <1-4094> address <H.H.H>	page 151
vlan members <1-4094> <portlist>	page 149
vlan members add <1-4094> <portlist>	
vlan members remove <1-4094> <portlist>	
vlan name <1-4094> <line>	page 147
vlan ports [<portlist>] [tagging {enable disable}] [pvid <1-4094>] [filter-tagged-frame {enable disable}] [filter-untagged-frame {enable disable}] [filter-unregistered-frames {enable disable}] [priority <0-7>] [name <line>]	page 148
web-server{enable disable}	page 69

Index

A

access 33, 66, 101, 105, 106, 115
accessing the CL 33
actions 180
age-out time 46
allowed IP addresses 101
alphabetical list of commands 187
ASCII config file 57
authentication 115
automatic configuration 57
automatic PVID feature 140
autonegotiation 76, 89
auto-pvid command 147
autotopology command 92

B

BaySecure 106
boot command 70
BootP 63
broadcast traffic 96

C

CI Main Menu 35
CI menus 19
clear logging command 84
clear-stats command 87
CLI 33
CLI command list, alphabetical 187

cli password command 36
command modes 28, 42
community string 77
configuration 19, 53
configure command 42
configure network command 57
connectivity 56
console port 33
conversation steering 135
COPS 168
copy config tftp command 73
copy configuration file 72
copy tftp config command 74
customer support 22

D

default autotopology command 93
default command 38, 41
default duplex command 91
default flowcontrol command 95
default ipbootp server command 71
default mac-address-table aging-time command 49
default rate-limit command 99
default set logging command 84
default snmp trap link-status command 81
default spanning-tree command 127, 130
default speed command 90
default telnet-access command 68

- default terminal command 54
- default vlan igmp command 155
- Device Manager 19, 103
- diagnostics 75
- disable command 43
- displaying logs 82
- download command 75
- downloaded configuration file 57
- DSCP 172
- duplex command 90
- duplex mode 76, 89

E

- eapol command 113
- EAPOL-based security 112
- egress map 172
- enable command 41
- end command 43
- Ethernet statistics 85
- event logs 82
- exit command 43

F

- FastLearn for spanning tree 120
- filter groups 174
- flow control 93
- flowcontrol command 94
- format 32, 33
- forwarding table 46

G

- gateway 59
- Gigabit Ethernet 93

H

- help 37, 38
- Hybrid Stack 49
- hybrid stack 27

I

- IEEE 802.1p 172
- IGMP 153
- ingress maps 172
- interface command 42
- interface groups 169
- interfaces 42, 169
- IP 33, 101
- IP address 59, 60, 61, 105
- IP address command 60
- ip bootp server command 70
- ip default-gateway command 61
- IP filter sets 174
- IP filters 174
- IP manager list 101
- ipmgr command 103, 105

L

- Layer 2 filter sets 174
- Layer 2 filters 174
- link status 87
- logging 82
- logout command 41

M

- MAC address 44, 46
- MAC address forwarding database table 46
- MAC source address-based security 106
- mac-address-table aging-time command 48
- mac-security command 107

mac-security command for a single port 111
mac-security mac-address-table address
command 108
mac-security mad-address-table address
command 108, 109, 110, 111
mac-security security-list command 109
management 19
management systems 103
MDA 93
meters 181
mixed stack 27
mixed stacks 26
MLT 76, 132
mlt command 133
monitoring 135
multicast traffic 96, 152
MultiLink Trunking 132
multiple spanning tree groups 120

N

netmask 33, 60
network configuration 57
no auto-pvid command 147
no autotopology command 93
no command 38
no flowcontrol command 94
no ip address command 61
no ip bootp server command 71
no ip default-gateway 62
no ipmgr command 104, 105
no mac-security command 110
no mac-security mac-address-table command 110
no mac-security security-list command 111
no mlt command 134
no port-mirroring command 137
no radius-server command 117

no rate-limit command 98
no set logging command 84
no shutdown command 88
no snmp-server command 79
no snmp trap link-status command 80
no spanning-tree command 131
no telnet-access command 67
no tftp-server command 73
no vlan command 146
no vlan mac-address command 151
no web-server command 69

P

passwords 36
ping command 56
policies 184
port number and port list 32
port statistics 85
port, enabling or disabling 87
portlist 32
port-mirroring 135
port-mirroring command 135
portnum 32
ports 89, 169
product support 22
protocol VLANs 140
publications 21
Pure BPS 2000 Stack 49
PVID 140

Q

QoS
802.1p 172
actions 158, 180
agent 158
COPS 168

- displaying parameters 158
- drop precedence 172
- DSCP 172
- egress maps 158, 172
- filter groups 158
- filter sets 158
- filters 158
- ingress map 172
- ingress maps 158
- interface groups 169, 170
- interfaces 158
- IP filters 174
- Layer 2 filters 174
- meters 158, 181, 183
- packet reordering 186
- policies 158, 184
- policing statistics 183
- queue sets 158, 172
- queues 186
- reset 168
- statistics 158
- qos action command 180
- qos egressmap command 172
- qos if-assign command 170
- qos if-assign-list command 171
- qos if-group command 170
- qos ingressmap command 173
- qos ip-filter command 175
- qos ip-filter-set command 176
- qos l2-filter command 177
- qos l2-filter-set command 179
- qos meter command 182
- qos policy command 184
- qos queue-set-assignment command 174
- qosagent packet-reordering command 186
- qosagent police-statistics command 183
- qosagent reset-default command 168
- qosagent server-control command 169
- queues 172

- quit 41

R

- RADIUS access 36
- RADIUS authentication 115
- radius-server command 116
- rate-limit command 97
- rate-limiting 96
- remote access requirements 64
- renumber unit command 46
- reordering packets 186
- requirements 33
 - accessing the CLI 33
 - remote access 64
 - terminal 33

S

- scripts 25, 42, 57
- security 36, 66, 101, 106, 112, 115
- security lists 106
- serial port 33
- set logging command 83
- show config-network command 59
- show eapol command 112
- show interfaces command 76
- show ip command 63
- show ipmgr command 102
- show logging command 82
- show mac-address-table command 47
- show mac-security command 106
- show mlt command 132
- show port-mirroring command 135
- show port-statistics command 85
- show qos command 158
- show radius-server command 115
- show rate-limit command 96

- show spanning-tree command 120
- show stack-info command 45
- show stack-oper-mode command 50
- show sys-info command 44
- show telnet-access command 65
- show terminal command 54
- show tftp-server command 72
- show vlan igmp command 153
- show vlan interface info command 141, 142
- show vlan interface vids command 142
- show vlan mac-address command 150
- show vlan multicast membership command 152
- shutdown command 87
- SNMP 77
- snmp trap link-status command 80
- snmp-server command 78
- snooping 153
- software version 44
- software, downloading 75
- source IP addresses 105
- spanning tree 120
- spanning-tree add-vlan command 127
- spanning-tree command 126, 129
- spanning-tree remove-vlan command 128
- spanning-tree stp create command 123
- spanning-tree stp delete command 124
- spanning-tree stp disable command 125
- spanning-tree stp enable command 124
- speed 76, 89
- speed command 89
- stack 76
- stack information 45
- stack operational mode
 - STGs 49
 - VLANs 49
- stack oper-mode command 50

- stacking 26
- standalone mode 32
- statistics 85, 158, 183
- STG 120
- subnet mask 33, 60
- support, Nortel Networks 22
- system contact 77
- system information 44
- system location 77
- system name 77

T

- Tab key navigation 38
- tagged frames 140
- technical publications 22
- technical support 22
- Telnet 33, 36, 64, 66, 103
- telnet-access command 66
- terminal command 55
- terminal 42
 - requirements 33
 - settings 54
- TFTP 72
- tftp-server command 73
- traffic
 - Gigabit Ethernet 93
 - rate-limiting 96
- traffic policing 181, 183
- traps 77, 80
- troubleshooting 33, 49, 51
 - access 41, 61, 64, 101, 106, 115
 - mixed stack 27
 - ping 56
 - port numbers 32
 - port-mirroring 135
 - ports 42
 - QoS 181, 183, 186
 - spanning tree 119, 120

- spanning tree groups 120
- stack 46
- stacks 26
- STG 120
- VLANs 139, 140, 141, 145
- trunks 132

U

- unregistered frames 140
- untagged frames 140
- upgrading diagnostics 75
- upgrading software 75
- utilizing trunks 132

V

- vlan create command 144
- vlan delete command 146
- vlan igmp command 154
- vlan mac-address command 151
- vlan members command 149
- vlan name command 147
- vlan ports command 148
- VLANs 140
 - creating 144
 - learning 144
 - MAC SA-based 150
 - number of 139
 - ports 140
 - protocol-based 144
 - spanning tree groups 120
 - STGs
 - stack 27
 - type 144

W

- Web-based management system 19, 103
- web-server command 69